


Melville Equipment Corp Pty Ltd

“Proud Australian Manufacturers”



108 - Spike Puller Operation Manual




Melville Equipment Corp Pty Ltd

Address: 10 Rogilla Close
MARYLANDNSW 2287
AUSTRALIA

Phone: 61 2 49 515 224 Fax: 61 2 49 501 291

Email: sales@melvelle.com.au Web: www.melvele.com.au

Notes:



Document Edition: 1.3

Updated Date: 14th February 2020



Table of Contents

TABLE OF CONTENTS.....	3
1. PREFACE	4
2. SAFETY INFORMATION	5
3. SAFETY SYMBOLS	6
3.1. SAFETY SYMBOLS & SIGNAL WORDS.....	6
3.2. HAZARD WARNING SIGNS.....	7
3.3. PERSONAL PROTECTION SYMBOLS	9
3.4. PROHIBITION SYMBOLS	10
4. SAFETY PRECAUTIONS	11
5. EQUIPMENT STICKERS & TAGS	14
5.1. STICKER LOCATION.....	17
6. EMERGENCY STOP	18
7. INTRODUCTION	19
8. SPECIFICATIONS	20
8.1. FP-108-AU	20
8.2. FP-108-BR.....	20
8.3. FP-108-EE	20
8.4. FP-108-EN /F.....	21
8.5. FP-108-TP/F	21
9. OPERATION	22
9.1. PRE-OPERATION CHECKS	22
9.2. ASSEMBLY PROCEDURES.....	25
9.3. OPERATION PROCEDURES	30
10. EQUIPMENT PROTECTION & CARE	35
11. MAINTENANCE.....	36
12. TROUBLESHOOTING	37
13. FURTHER DOCUMENTS.....	38
13.1. OPERATIONAL RISK ASSESSMENT	39
13.2. 108 SPIKE PULLER HYDRAULIC CIRCUIT DIAGRAM.....	42
13.3. MEC BASE LEVEL HEAD (MAIN PARTS).....	43
13.4. HONDA PETROL RECOIL START DEDICATED MACHINE	44
13.5. HONDA PETROL ELECTRIC START DEDICATED MACHINE.....	45
13.6. YANMAR DIESEL ELECTRIC START DEDICATED MACHINE	46
13.7. MEC TRACKPACK HEAD	47
13.8. TROLLEY TO POWER PACK ATTACHMENT	53
13.9. TRACK PACK HEAD WITH SWIVEL FOOT.....	54
13.10. LOWER LEVEL TRACK PACK HEAD DUAL HANDLE.....	55
13.11. TRACK PACK HEAD SLIDING LEG HOUSING	56
13.12. HYDRAULIC CIRCUIT DIAGRAM DUAL TRIGGER MANIFOLD	57
13.13. TRACKPACK BOOM ADJUSTMENT.....	58



1. Preface

Every attempt has been made to present accurate and current information within this manual. However, as product development on the Spike Puller and components used within is continuous, the information contained herein may be subject to change without notice, and without incurring obligation.

The information provided within this manual is the sole property of Melville Equipment Corporation Pty Ltd (MEC) and as such, reproduction or replication of any material contained within is not allowed without the written consent of MEC.

Information provided within this manual assumes:

- The person(s) operating the machinery have read and understand this manual and other manuals provided for specific components
- The person(s) operating are properly trained and equipped to safely and professionally operate this machinery
- The person(s) operating utilise the correct attachments and/or tools, and are trained and equipped to use them safely and professionally

SERVICING THE 108 Spike Puller

This manual contains safety, operation and periodic maintenance instructions. MEC recommends that servicing of equipment, other than periodic maintenance, must be performed by MEC or certified and authorised dealer. Please read the following warning.



SERIOUS INJURY OR DEATH COULD RESULT FROM THE IMPROPER REPAIR OR SERVICE OF THIS EQUIPMENT.

REPAIRS AND / OR SERVICE OF THIS EQUIPMENT MUST ONLY BE PERFORMED BY MELVILLE EQUIPMENT CORP. PTY LTD. OR CERTIFIED AND AUTHORISED DEALER.



2. Safety Information

This operation and training manual is intended to complement existing site procedures.

The following site documentation must be reviewed by the trainee before commencing training:

- Safe Work Procedures (SWP)
- Isolation Procedures

If the training package information conflicts with existing site documentation, then the authorised site and/or end user is to consult with MEC in regards to any possible amendments or modifications required.

The following practices and procedures must be adhered to:

- Always complete Pre-Operation Checks prior to use and report any defects if found
- Only connect equipment with compatible MEC equipment
- Only operate the equipment for its intended purpose
- Never operate with guards missing or damaged
- PPE Equipment as a minimum should be worn at all times according to this manual and as per site specifications
- Ensure Isolation Procedures are followed prior to carrying out any maintenance
- If any faults or damage to this machine are found during pre-operation checks or operation, tag the machine “Out-of-Service” and follow site procedures


Following the above mentioned and the information contained within this manual will ensure safe, efficient operation of the equipment.



3. Safety Symbols








The safety symbols and signal words, as shown below, are used to emphasise all operator, maintenance and repair actions which, if not strictly followed, could result in a life-threatening situation, bodily injury or damage to the equipment.

3.1. Safety Symbols & Signal Words







	This safety alert and signal word indicates a hazardous situation which, if not avoided, <u>will</u> result in <u>death or serious injury</u> .
	This safety alert and signal word indicates a potentially hazardous situation which, if not avoided, <u>could</u> result in <u>death or serious injury</u> .
	This safety alert and signal word indicates a potentially hazardous situation which, if not avoided, <u>may</u> result in <u>minor or moderate injury</u> .
	This signal word indicates a potentially hazardous situation which, if not avoided, <u>may</u> result in <u>property damage</u> .
	This signal word indicates a situation which, if not avoided, <u>will</u> result in <u>damage to the equipment</u> .
	This signal word indicates a situation which, if not avoided, <u>may</u> result in <u>damage to the equipment</u> .









3.2. Hazard Warning Signs

	This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all instructions to avoid possible injury or death.
	This is the fire risk symbol. It is used to alert you to the potential of a fire starting if ignition sources are present.
	This is the explosive risk symbols. It is used to alert you to the potential of an explosion /explosive substances present.
	This is the toxic hazard symbol. It is used to alert you to the presence of toxic substances.
	This is the corrosive risk symbol. It is used to alert you to the presence of corrosive substances.
	This is the electric shock risk symbols. It is used to alert you to the presence of an electrical supply.
	This is the battery symbol. It is used to alert you to the potential hazard of electrical supply, battery acid and leaking batteries.





	This is the hot surface symbol. It is used to alert you that the surfaces may be hot.
	This is the dangerous gases symbol. It is used to alert you to the presence of dangerous gases.
	This is the fluid under pressure symbol. It is used to alert you that there are fluids under pressure in this machinery.
	This is the sharp edges symbol. It is used to alert you to the presence of sharp edges or cutting hazard.
	This is the keep hands clear symbol. It is used to warn you to keep hands clear as there are pinch points present.
	This is the rotating parts symbols. It is used to warn you of rotating parts on the machinery. Keep clear of rotating parts.


3.3. Personal Protection Symbols

	<p>This is the eye protection symbol. It is used when eye protection must be worn.</p>
	<p>This is the hearing protection symbol. It is used when hearing protection must be worn.</p>
	<p>This is the head protection symbol. It is used when head protection must be worn.</p>
	<p>This is the hand protection symbol. It is used when hand protection must be worn.</p>
	<p>This is the foot protection symbol. It is used when feet protection must be worn.</p>
	<p>This is the protective body clothing symbol. It is used when protective clothing must be worn.</p>



	<p>This is the face protection symbol. It is used when face protection must be worn.</p>
	<p>This is the long hair protection symbol. It is used when long hair is required to be contained or restrained.</p>

3.4. Prohibition Symbols

	<p>This is the naked flame symbol. It is used when there is not to be a fire, naked flame, ignition sources and smoking nearby.</p>
---	---

4. Safety Precautions

To ensure safe operation, please read and understand the following statements and their meanings. Also refer to supporting manuals from the engine manufacturer on specific operation and maintenance of the engine. This manual contains safety precautions which are outlined below.



Ensure all personnel operating this equipment are properly trained to ensure safe operation



Wear personal protective equipment around this machinery.

For example: safety glasses, hearing protection, head protection, protective clothing and safety shoes at all times.



Accidental Starts can cause severe death or injury.

Disable engine by disconnecting negative (-) battery cable. Ensure machinery is started in the neutral position.



Rotating parts can cause severe injury

Stay away whilst machine is in operation. Ensure ALL guarding is in place and secured before operation.



Hot parts can cause severe burns.

Do not touch machinery whilst in operation.



! WARNING



Carbon monoxide can cause severe nausea, fainting or death.

Avoid inhaling exhaust fumes and never operate the engine in a closed or refined area.

! WARNING



Fuel can cause fires and severe burns.

Do not fill the fuel tank while the engine is hot or running.

! WARNING



Explosive gas can cause fires and severe acid burns.

Charge battery only in a well-ventilated area. Keep sources of ignition away.

! WARNING



High Pressure fluids can puncture skin and cause severe injury or death.

Do not work on fuel or hydraulic system without proper training and safety equipment. Ensure all hose connections are tight.

! WARNING



Clamping parts can cause severe injury.



Stay away whilst machine is in operation. Ensure ALL guarding is in place and secured before operation.



! WARNING







Loose hair, clothing and jewellery can cause severe injury.





<p>Electrical shock can cause injury. Do not touch wires whilst engine is running.</p>

<p>Ensure hair is restrained; loose clothing not to be worn and jewellery must be removed before operating the machinery.</p>


<p>Attachment hoses must have a minimum working pressure rating of 3000psi. Do not use hoses and fittings that are not pressure rated.</p>



<p>Ignition sources can cause fires and severe burns. There is <u>not</u> to be a fire, naked flame, ignition sources or smoking around any MEC machinery.</p>



<p>Toxic and/or Hazardous substances utilised in this machinery. Beware of toxic and/or hazardous substances used within this machinery. Do not inhale, swallow or touch toxic/hazardous substances.</p>


5. Equipment Stickers & Tags

Below are the stickers and tags utilised on this equipment.

Melville Equipment Corp P/L
10 Rogilla Close Maryland NSW 2287, Australia
Ph +61 2 4951 5244, Fax +61 2 4950 1291
E-mail Sales@melville.com.au www.melville.com.au
Our products are protected by one or more of the following patents or registered designs. 101614, 101645, 101678, 101679, 560853, WO2012/083339 + INT patents

M/N _____

S/N _____



IDTAG02 – Model & Serial No. Tag



IDTAG12 – Emergency Stop Warning Label

SPIKE PULLER HEAD ADJUSTMENT				
The various spacers at the puller head swivel, adjust the swivel foot to sit flat on the sleeper. The swivel foot must sit flat on the sleeper for stable pulling of the dog & lock spikes				
31Kg/m rail	= 0	spacers	under	the boom.
41 to 47Kg/m	=1	"	"	"
50 to 57Kg/m	=2	"	"	"
60Kg/m rail	=3	"	"	"

IDRLHEI - Rail Height Spacer Tag





MELVELLE EQUIPMENT
NEWCASTLE NSW 2287 AUSTRALIA
PHONE: +61-2-4951 5244 EMAIL: sales@melville.com.au
WEB: www.melville.com.au

LAB0003 – Melville Newcastle Sticker



**MELVELLE EQUIPMENT
CORP PTY LTD**

Achieving Excellence

10 Rogilla Close, Maryland (Newcastle)
NSW, 2287, Australia.
ABN 55 123 570 356

Phone: +61-2-4951 5244
Fax: +61-2-4950 1291
Email: sales@melville.com.au
Web Site: www.melville.com.au

LAB0004 – Melville Achieving Excellence Sticker



LAB0006 – Danger – Keep Hands and Feet Clear Sticker



LAB0008 – Safety Label






LAB0017 - Approximate Weight 50Kg



5.1. Sticker Location



6. Emergency Stop

This machine has been fitted with an Emergency Stop to increase the operational safety of MEC machinery.



Important information about the Emergency Stop:

- The Emergency Stop is designed to stop the engine and hence the work head
- Dedicated machines have a dedicated Emergency Stop to the power pack – they are wired into the machine
- Trackpacks fitted with a wiring harness **WILL NOT OPERATE** unless a work head with an Emergency Stop is connected and the wiring harness connectors are joined
- The Emergency Stop **WILL NOT OPERATE** unless it is electrically connected to the power pack. For Trackpack heads, if the Trackpack is not fitted with a wiring harness and plug, the Emergency Stop will not work



7. Introduction

Melville Equipment Corp Pty Ltd (MEC) supply spike pullers to the rail industry. The 108 spike puller is designed to remove both dog and lock spikes used in fastening rail plates to sleepers. The 108 spike puller has the ability to be used on rail sizes from 31kg/m to 68kg/m rail with a variety of rail plates.

The 108 work head removes both dog and lock spikes using hydraulic force rather than operator exertion. This significantly improves efficiency and eliminates manual handling hazards associated with removing rail spikes.

Producing 9.5 tonnes of force, spikes in swollen sleepers are easily removed. The 108 spike puller can remove spikes quickly and with ease reducing removal time and effort.

The 108 work head is packed with features making it a valuable tool for track maintenance and construction. They include:

- Quick change between style of jaws (dog and lock spike)
- Maintenance free – no greasing
- Ergonomic, height adjustable handles
- Precisely balanced – only 3-5 kg on operator
- Lifting bar

With safety being Melville's 1st priority the 108 workhead has been design with the following safety features:

- Fully guarded – there is no access to pinch or crush points.
- “dead man” switch requiring two handed operation.
- e-stop
- All hydraulic hoses are fitted with hose protection



8. Specifications

8.1. FP-108-AU

Engine	13HP Honda® Petrol Recoil Start
Dimensions	2000mm long x 740mm wide x 1100mm high
Weight (wet)	130kg
Pressure System (max)	182.5bar / 2650psi
Pump Flow	32.5L/min
Fuel Type	Petrol
Battery	N/A
Hydraulic Oil*	ISO68
Hydraulic Hose Connection Size	½"
Pressure Settings:	
Pressure set on Relief	182.5bar / 2650psi
Pressure set on Kickdown	62bar / 900psi

8.2. FP-108-BR

Engine	13HP Honda® Petrol Electrical Start
Dimensions	2000mm long x 740mm wide x 1100mm high
Weight (wet)	140kg
Pressure System (max)	182.5bar / 2650psi
Pump Flow	32.5L/min
Fuel Type	Petrol
Hydraulic Oil*	ISO68
Hydraulic Hose Connection Size	½"
Pressure Settings:	
Pressure set on Relief	182.5bar / 2650psi
Pressure set on Kickdown	62bar / 900psi

8.3. FP-108-EE

Engine	7HP Yanmar® Diesel Electric Start
Dimensions	2000mm long x 740mm wide x 1100mm high
Weight (wet)	145kg
Pressure System (max)	182.5bar / 2650psi
Pump Flow	30L/min
Fuel Type	Diesel
Battery	12V
Hydraulic Oil*	ISO68
Hydraulic Hose Connection Size	½"
Pressure Settings:	
Pressure set on Relief	182.5bar / 2650psi
Pressure set on Kickdown	62bar / 900psi



8.4. FP-108-YE

Engine	7HP Yanmar® Diesel Electric Start
Dimensions	2200mm long x 740mm wide x 1000mm high
Weight (wet)	167kg
Pressure System (max)	150.5bar / 2182.8psi @ 15 L/min (2200 rpm)
Pump Flow	24L/min @ 100 Bar/1450 psi (3600 rpm)
Fuel Type	Diesel
Battery	12V
Hydraulic Oil*	ISO68
Hydraulic Hose Connection Size	½"
Pressure Settings:	
Pressure set on Relief	182.5bar / 2650psi
Pressure set on Kickdown	55bar / 800psi

8.5. FP-108-EN /F

Engine	MEC Trackpack
Dimensions	500mm long x 400mm wide x 1100mm high
Weight (wet)	41kg
Pressure (max)	182.5bar / 2650psi
Pump Flow	32.5L/min
Fuel Type	MEC Trackpack
Battery if Applicable	12V
Hydraulic Oil*	ISO68
Hydraulic Hose Connection Size	½"
Pressure Settings:	
Pressure set on Relief	182.5bar / 2650psi
Pressure set on Kickdown	62bar / 900psi

8.6. FP-108-TP/F

Engine	MEC Trackpack
Dimensions	500mm long x 400mm wide x 1100mm high
Weight (wet)	56kg
Pressure (max)	182.5bar / 2650psi
Pump Flow	32.5L/min
Fuel Type	MEC Trackpack
Battery if Applicable	12V
Hydraulic Oil*	ISO68
Hydraulic Hose Connection Size	½"
Pressure Settings:	
Pressure set on Relief	182.5bar / 2650psi
Pressure set on Kickdown	55bar / 800psi

*The type of hydraulic oil depends on ambient air temperatures. ISO68 is a good, general purpose oil for ambient conditions between 10-30°C. If the ambient temperature is between 0-10°C use the next lighter oil grade. If the ambient temperature is between 30-50°C, use the next heavier oil grade.



9. Operation

9.1. Pre-Operation Checks

Overall Inspection

1. Check that the equipment is free from damage or defects
2. If damaged, DO NOT USE. Contact MEC for repairs

Engine Oil

1. Check the level and quality of the engine oil. Add if required
2. If contaminated or old, engine oil will be dark (nearly black)
3. If contaminated with water, engine oil will be a milky colour
4. Refer to manufacturer's instructions for specific data
5. If engine oil contaminated, replace before use

Hydraulic Oil

1. Check the level and quality of the hydraulic oil and add if required
2. Oil level to be just above the centre cone under the filter breather cover by 2-20mm
3. If contaminated, hydraulic oil will be discoloured
4. If contaminated with water, hydraulic oil will be a milky colour
5. If hydraulic oil contaminated, replace before use

Fuel

1. Check the level of fuel and add if required



Battery (if applicable)

1. Visually inspect the condition of the battery
2. Ensure there is no damage, acid levels are OK and the battery leads are free from defects
3. If damaged, replace before use

Halogen Light (if applicable)

1. Visually inspect condition and leads of light
2. Ensure there is no damage and leads are free from defects
3. Before starting, ensure the light is off
4. If damaged, replace before use

Hydraulic Hoses & Filter

1. Visually inspect the hoses and filter
2. Ensure there is no damage
3. If damaged, replace before use

Emergency Stop

1. Ensure Emergency Stop plug is electrically connected
2. Ensure the wires are free from damage and connections are clean and dry

Jaws

1. Inspect both jaws for damage and wear before use
2. Ensure the jaws are free to slide and rotate
3. If damaged or excessive wear seen, replace jaws as a pair



Braking System

1. If an electric brake switch is being used ensure the wires are free from damage and connections are clean and dry.
2. If a manual pull style cable is being used ensure the cable is free from kinks and damage and the adjustment is correct
3. Ensure the brake lever operates smoothly and freely.
4. Ensure the brake hose is free from damage and connects to the trolley.




9.2. Assembly Procedures



Before any assembly and/or maintenance are performed, ensure the work head and engine are off and in a neutral position

9.2.1. Machine Trolley

1. Inspect the trolley and ensure it is not damaged and free from defects.
2. The machine trolley weighs approximately 36kg. Using a minimum of 2 people or certified lifting device, lift the trolley onto the rail lines. This can be achieved by lifting from the cross bar (tube).
3. Ensure the trolley sits stationary until the Spike Puller is assembled to it.





9.2.2. Machine Assembly – Dedicated Machine

1. Observe all safety precautions.
Ensure the operation is being performed on safe and steady ground (no excessive slopes or dangerous terrain).
2. Inspect the Spike Puller and ensure it is not damaged and is free from defects.
3. A dedicated Spike Puller Machine weighs approximately 150kg. Using a certified lifting device (min 200kg), attach slings or a lifting hook to the lifting point on the machine.
4. By following safe lifting procedures, lift the machine onto the trolley. The cross trolley rollers will sit onto the cross bar (tube).




When placing the machine onto the trolley, ensure hands are clear of the cross trolley rollers and cross bar (tube) as personal injury may occur.

5. By attaching the Spike puller to the trolley, the head will rest on the ground and stop the trolley from moving.
6. Remove the slings and/or hooks. The machine can now be moved to either rail for use. This is achieved by raising the head off the ground and sliding across the trolley. A second person may be required to assist and push the engine across the trolley.
7. Attach the chain to the trolley to ensure the machine will not roll during operation.
The machine is now ready for use.



9.2.3. Machine Assembly – Trackpack

1. Observe all safety precautions. Ensure the operation is being performed on safe and steady ground (no excessive slopes or dangerous terrain).
2. Inspect the Spike puller Head and Trackpack and ensure they are not damaged and are free from defects.
3. A Trackpack Spike puller Head weighs approximately 45 kg and a Trackpack weighs approximately 100kg.
4. Place the work head onto ground standing upright (Follow safe lifting procedures)
5. Adjust the pivot position (cross trolley rollers) to the correct position for the machine. For the Spike puller this is the second hole from the engine (refer further document drawing for pin locations). Attach slings to the Trackpack.
6. By following safe lifting procedures, lift the Trackpack using slings ensuring it is kept level and easy to move.
7. Using at least two people hold the Work head steady and Guide the Trackpack towards the work head and align the square attachment (hayman-reese style) and slide the items together. Insert the locking pin between the items. Lower the Trackpack to the ground and remove the slings.
8. Connect the hydraulic quick snaps, electrical connector plug as well as the manual pull brake cable if fitted to the track pack.
9. The Trackpack and work head are now attached and can be lifted onto the machine trolley. Refer above for procedure on attaching to machine trolley.




9.2.4. Machine Adjustment – Rail Size

The Spike puller machine has the ability to be utilised on 31-68kg rail and those in between. This is achieved through the use of predetermined spacers under the front pivot pin for each of the rail sizes. These are:

Rail Size	Spacer placement
31kg/m	No Spacers under the boom
41-47kg/m	1 spacer under the boom
53-57kg/m	2 spacers under the boom
60-68kg/m	3 spacers under the boom

To adjust the Spike Puller:


1. Ensure the machine is off and safe to be worked on.
2. Support Work head and loosen nut at end of boom that allows rotation of the Work head
3. Separate the head and boom and place the correct number of spacers from the table above onto the work head pin. Slide the boom back onto the head and place the rest of the spacers onto of the boom so the spacers are not lost. Tighten the nut back up.
4. For correct alignment the workhead must be square and perpendicular to the sleeper. Incorrect adjustment can lead to excessive kicking of the machine.



9.2.5. Jaw Selection

The Spike Puller machine has the ability to both remove lock spikes and dog spikes with the use of different jaws (Note: Machine is originally supplied with both sets of jaws)

1. Support the work head of the machine so clear access can be gained to the lower portion of the work head
2. Remove the lower swivelling jaw assembly by the 4 bolts
3. Remove the pin holding the jaws together and swap out with the correct jaws as shown below.
4. Reassemble the jaw housing



Lock Spike Jaw



Dog Spike Jaw

9.3. Operation Procedures

9.3.1. Starting the Engine – Electric Start¹

1. Observe all safety precautions
2. Ensure all pre-operation checks have been conducted
3. Ensure the Spike Puller is on safe and steady grounding (no excessive slopes or dangerous terrain conditions)
4. Attach tooling hoses to power pack. Ensure the snap connectors are clean and tool is in 'NEUTRAL' position (trigger in fully down position)
5. Ensure Emergency Stop is electrically connected to power pack and not engaged
6. Ensure Fuel Solenoid switch is down (if applicable)
7. Place the throttle at 50% power
8. Turn the key to its first position (on position)
9. Turn key to second position (starting position). Hold until engine starts and the release, allowing the key to return to its first position
10. Place throttle in idle (min) position and allow engine to warm up – refer manufacturers manual for required times
11. Move throttle to required rpm position, normally full throttle²
12. Power pack and hydraulic circuit are now in operation and tooling is able to be used. Refer to Equipment Operation for instructions on using tooling

¹ Refer to engine manual for detailed engine instructions and requirements

² During first 50hrs do not exceed 70% maximum rated power



9.3.2. Starting the Engine – Recoil Start¹

1. Observe all safety precautions
2. Ensure all pre-operation checks have been conducted
3. Ensure the Spike Puller is on safe and steady grounding (no excessive slopes or dangerous terrain conditions)
4. Attach tooling hoses to power pack. Ensure the snap connectors are clean and tool is in 'NEUTRAL' position (trigger fully down)
5. Ensure Emergency Stop is electrically connected to power pack and not engaged
6. Ensure Fuel Solenoid switch is down (if applicable)
7. Place the throttle at 50% power
8. Turn the key to its first position (on position)
9. Hold the grip and pull the cord until compression is found
10. Completely rewind the cord (allow to retract)
11. Operate the decompression lever (push down)
12. Using two hands, firmly and quickly pull the cord to start
13. Place throttle in idle (min) position and allow engine to warm up – refer manufacturers manual for required times
14. Place throttle at required rpm position, normally full throttle²
15. Power pack and hydraulic circuit are now in operation and tooling is able to be used.
Refer to Equipment Operation for instructions on using tooling


¹ Refer to engine manual for detailed engine instructions and requirements

² During first 50hrs do not exceed 70% maximum rated power




9.3.3. Equipment Operation – Spike pulling old version

1. Observe all safety precautions
2. Ensure all pre-operation checks have been conducted
3. Ensure the Spike Puller is on safe and steady grounding (no excessive slopes or dangerous terrain conditions)
4. Ensure the correct spacers are under the workhead. (Refer pre operation checks for details)
5. Start the engine as per Starting the Engine instructions (listed above)
6. Pull the trigger up to the first position to extend the cylinder down to expose the jaws.
7. Depress the brake lever and place the Work head over the Spike making contact between the jaws and the spike. Squeeze the trigger to engage the cylinder and to pull the spike out. NOTE - Actual equipment operation is performed between the top position and middle position of the trigger. Bottom position is only for starting/stopping the engine (neutral position)
8. Release the trigger to lower the jaws and allow the spike to fall onto the ground
9. Move onto the next spike and repeat the process.



9.3.4. Equipment Operation – Spike Pulling Dead man handle

1. Observe all safety precautions
2. Ensure all pre-operation checks have been conducted
3. Ensure the Spike Puller is on safe and steady grounding (no excessive slopes or dangerous terrain conditions)
4. Ensure the correct spacers are under the workhead. (Refer pre operation checks for details)
5. Start the engine as per starting the engine instructions (listed above)
6. Pull the left trigger up to extend the cylinder down to expose the jaws.
7. Depress the brake lever and place the Work head over the Spike making contact between the jaws and the spike. Squeeze the right trigger to engage the cylinder and to pull the spike out. Allow the cylinder to travel to the top of its stroke to ensure the jaws open to release the spike.
8. Release the right trigger to lower the jaws back down to expose the jaws.
9. Move onto the next spike and repeat the process.



9.3.5. Stopping the Engine¹

1. Place tooling and power pack to “NEUTRAL” position
2. Set the engine speed to idle (min) using accelerator
3. Turn the ignition key to OFF

9.3.6. Lifting the Machinery

1. DO NOT manually lift machinery
2. Observe all safety precautions
3. Ensure all pre-operation checks have been conducted
4. Attach slings or hooks into lifting points on the machinery – see Further Documents for details
5. Using a certified lifting device to >200kg, lift the machinery to required position

¹ Refer to engine manual for detailed engine instructions and requirements



10. Equipment Protection & Care

NOTICE

In addition to the Safety Precautions found in this manual and the supporting tool and engine manuals, observe the following for equipment protection and care

- Make sure all couplers/connectors are wiped clean before connection
- The hydraulic circuit control valve in “NEUTRAL” position when coupling or uncoupling hydraulic tools. Failure to do so may result in damage to the couplers and cause overheating of the hydraulic system
- Always store hoses coupled together in a ‘loop’ to stop hydraulic lock due to the hoses and hydraulic oil heating
- Always store the Machine in a clean dry space, safe from damage or pilferage
- Make sure the power pack hydraulic circuit PRESSURE hose (male quick disconnect) is connected the PRESSURE hose for the tool (female quick disconnect) and vice versa for the RETURN hoses. Do not reverse circuit flow. This can cause damage to the internal seals of the equipment
- Always replace hoses, couplings and other components with replacement parts recommended by MEC. Hydraulic hoses must have a minimum working pressure of 2800psi
- Always keep critical tool markings such as warning stickers and tags legible
- Power pack and tooling repairs and/or service work must only be performed by MEC or certified and authorised dealer
- Do not use the power pack and/or tooling for applications for which it is not intended
- Ensure all bolts are tight and all covers/guards are fitted



11. Maintenance

REGULAR SERVICE PERIOD*		Each use	Every 1 month or 10hrs	Every 3 months or 50hrs	Every 6 months or 250hrs	Every year or 500hrs
Perform at every indicated month or operating hour interval, whichever comes first.						
ITEM						
Engine oil	Check level	X				
	Change			X (1)	X	
Engine oil filter	Change			X (1)		X
Fuel lines	Check		X			
Fuel Filter	Change					X
Air cleaner	Clean		X			
Engine cooling fins	Clean					X
Rocker arms clearance	Check & set					X (2)
Injectors	Clean & set					X (2)
Hydraulic oil Filter	Change			X (1)	X	
Hydraulic oil	Check	X				
	Change				X	
Hydraulic hoses	Check	X				
	Check/Change					X (3)
Hydraulic pump	Check			X (1)		X (4)
Battery	Check	X				
Grease Nipples	Fill			X		
Nuts, Bolts, Screws, Fittings	Check					X

*If heavy machine use, the service period may be less.

- (1) First 50 hrs of use
- (2) Only to be performed by MEC or certified and authorised dealer.
- (3) A thorough inspection is required. If hoses undamaged, may leave in service. However, replace hoses every 3 years of operation.
- (4) Flow and Pressure Check



12. Troubleshooting¹

PROBLEM	POSSIBLE CAUSE	CORRECTION
Engine won't start	Refer to engine manual for details	
	Battery charge low	Charge battery
	Battery connections loose/not attached	Check battery connections
	Emergency Stop not connected	Check Emergency stop connection
	No engine oil	Check engine oil
	No fuel	Check fuel quantity
	Fuel filter blocked	Check fuel filter
	Fuel solenoid is off	Check fuel solenoid position
No hydraulic oil flow/little flow	No hydraulic oil	Check hydraulic oil level
	Pressure and Tank (return) hoses interchanged	Check connection.
	Operation lever in neutral	Check operation lever position
	Couplers or hoses blocked	Remove restriction
	Filter Blocked or Old	Replace filter
	Hoses leaking	Check hoses
	Contamination in relief valve	Clean relief valve
	Pump damaged	Check pump
Hydraulic oil overheating	Air obstruction	Remove obstruction to ensure sufficient air flow around heat exchanger
	Incorrect oil for operating temperature	Replace oil with correct grade for operating conditions
	Dirty/old oil	Replace oil
	Tool valve closed	Change tool or valve to 'open centre'
Unable to connect hoses	Oil temperature and pressure increase in hoses	Allow hoses to cool
	Operation lever in operation position	Place lever in neutral
Emergency Stop does not work	Emergency Stop not connected to the machine	Connect Emergency Stop to the power pack
	Wiring and/or connections damaged	Inspect wiring and replace damaged parts
	Switch Damaged	Check/Replace switch
Cylinder Will not extend	Damaged spool	Check/replace spool/seals
	No oil flow	Check circuit and pressures
	Damaged seals	Replace seals
	Damaged rod or piston	Inspect for straightness. Replace if out of tolerance.

¹ Refer to engine manual for detailed engine instructions and requirements



13. Further Documents

Please refer to the further documents within for drawing, risk assessment and other related information.

Further documents for the 108 Spike Puller:

Document No.	Description	Type	Pg. #
108-OPRA	Operational Risk Assessment	Document	39
108-22	108 Spike Puller Hydraulic circuit diagram	Drawing	42
108-101	MEC Base Level Head (Main Parts)	Drawing	43
108-202	Honda Petrol Recoil Start Dedicated Machine	Drawing	44
108-203	Honda Petrol Electric Start Dedicated Machine	Drawing	45
108-204	Yanmar Diesel Electric Start Dedicated Machine	Drawing	46
108-567	FP-108-YE - Yanmar Diesel Electric Start Dedicated Machine	Drawing	47
108-207	MEC Trackpack Head	Drawing	52
108-215	Trolley to Power Pack Attachment	Drawing	53
108-388	Track pack head with swivel foot	Drawing	54
108-389	Lower level Track pack head dual handle	Drawing	55
108-390	Track pack head sliding leg housing	Drawing	56
108-393	Hydraulic circuit diagram dual trigger manifold	Drawing	57
143-48	Trackpack Boom Adjustment	Drawing	58



13.1. Operational Risk Assessment

Machine: FP-108 - SPIKE PULLER					Form No.:																																																																																																																					
ABN					Issue Date		26/04/2012																																																																																																																			
WORKPLACE GENERIC HIRARC FORM					Version:		0																																																																																																																			
Company	MELVELLE EQUIPMENT CORP	Department / Workplace:	Melville Offices	Date of Assessment 26-4-2012	Commenced:	9am	Completed:	10am																																																																																																																		
Scope of Assessment: Identify the risks and hazards associated with the operation of a rail maintenance machine to remove spikes from railway sleepers in situ tracks.																																																																																																																										
Names of Risk Assessment Team: Gary Morris, Adrian Gersbach				Names of additional personnel consulted during Risk Assessment:		Identified limitations of risk assessment: Only applies to risks identified as part of the operation of the machine.																																																																																																																				
						Information Sources / References: AS4024.1-2006 Safety of Machinery,																																																																																																																				
<table border="1"> <thead> <tr> <th colspan="8">RISK ASSESSMENT MATRIX</th> </tr> <tr> <th colspan="3" rowspan="2">Potential Consequences</th> <th colspan="5">Likelihood</th> </tr> <tr> <th>Almost Certain</th> <th>Likely</th> <th>Possible</th> <th>Unlikely</th> <th>Rare</th> </tr> <tr> <th>Keyword</th> <th>Description Safety Health & Hygiene</th> <th>Description Environmental</th> <th>Expected to occur</th> <th>Will occur occasionally</th> <th>May Occur</th> <th>Not expected to occur</th> <th>Requires unusual chain of events</th> </tr> </thead> <tbody> <tr> <td>Minor</td> <td>First Aid Injury</td> <td>On-site release immediately contained with business unit resources</td> <td>Medium 8</td> <td>Medium 7</td> <td>Low 3</td> <td>Low 2</td> <td>Low 1</td> </tr> <tr> <td>Significant</td> <td>Medical Treated Injury or illness</td> <td>On-site release or offsite release immediately contained with smelter resources</td> <td>High 14</td> <td>Medium 10</td> <td>Medium 9</td> <td>Low 5</td> <td>Low 4</td> </tr> <tr> <td>Serious</td> <td>Lost Time Injury or illness</td> <td>Off-site release causing nuisance or community complaint. Breach of license condition</td> <td>High 16</td> <td>High 15</td> <td>Medium 12</td> <td>Medium 11</td> <td>Low 6</td> </tr> <tr> <td>Severe</td> <td>Fatality or Permanently disabling injury of illness</td> <td>Off-site release with detrimental impact to environment or community. Repeated breach of license conditions</td> <td>Extreme 24</td> <td>Extreme 22</td> <td>High 20</td> <td>High 18</td> <td>Medium 13</td> </tr> <tr> <td>Disastrous</td> <td>Multiple Fatalities or work-related fatal diseases</td> <td>Toxic release off-site with detrimental impact to environment or community</td> <td>Extreme 25</td> <td>Extreme 23</td> <td>Extreme 21</td> <td>High 19</td> <td>High 17</td> </tr> <tr> <td colspan="3">LEGEND</td> <td colspan="3">ACTION REQUIRED</td> <td colspan="3">NOTIFY</td> </tr> <tr> <td colspan="3">LOW 1-6</td> <td colspan="3">Tolerable - Manage by Routine Procedures</td> <td colspan="3"></td> </tr> <tr> <td colspan="3">MEDIUM 7-13</td> <td colspan="3">Risk reduction required to "As low as Reasonably Practicable" ALARP</td> <td colspan="3">Design Team/Engineer</td> </tr> <tr> <td colspan="3">HIGH 14-20</td> <td colspan="3">Immediate action required to reduce risk. Authorisation required before proceeding on task</td> <td colspan="3">CEO</td> </tr> <tr> <td colspan="3">EXTREME 21-25</td> <td colspan="3">Intolerable. Cease activity until controls in place to reduce risk. Immediate & urgent Senior Management Team action required</td> <td colspan="3">CEO</td> </tr> </tbody> </table>									RISK ASSESSMENT MATRIX								Potential Consequences			Likelihood					Almost Certain	Likely	Possible	Unlikely	Rare	Keyword	Description Safety Health & Hygiene	Description Environmental	Expected to occur	Will occur occasionally	May Occur	Not expected to occur	Requires unusual chain of events	Minor	First Aid Injury	On-site release immediately contained with business unit resources	Medium 8	Medium 7	Low 3	Low 2	Low 1	Significant	Medical Treated Injury or illness	On-site release or offsite release immediately contained with smelter resources	High 14	Medium 10	Medium 9	Low 5	Low 4	Serious	Lost Time Injury or illness	Off-site release causing nuisance or community complaint. Breach of license condition	High 16	High 15	Medium 12	Medium 11	Low 6	Severe	Fatality or Permanently disabling injury of illness	Off-site release with detrimental impact to environment or community. Repeated breach of license conditions	Extreme 24	Extreme 22	High 20	High 18	Medium 13	Disastrous	Multiple Fatalities or work-related fatal diseases	Toxic release off-site with detrimental impact to environment or community	Extreme 25	Extreme 23	Extreme 21	High 19	High 17	LEGEND			ACTION REQUIRED			NOTIFY			LOW 1-6			Tolerable - Manage by Routine Procedures						MEDIUM 7-13			Risk reduction required to "As low as Reasonably Practicable" ALARP			Design Team/Engineer			HIGH 14-20			Immediate action required to reduce risk. Authorisation required before proceeding on task			CEO			EXTREME 21-25			Intolerable. Cease activity until controls in place to reduce risk. Immediate & urgent Senior Management Team action required			CEO		
RISK ASSESSMENT MATRIX																																																																																																																										
Potential Consequences			Likelihood																																																																																																																							
			Almost Certain	Likely	Possible	Unlikely	Rare																																																																																																																			
Keyword	Description Safety Health & Hygiene	Description Environmental	Expected to occur	Will occur occasionally	May Occur	Not expected to occur	Requires unusual chain of events																																																																																																																			
Minor	First Aid Injury	On-site release immediately contained with business unit resources	Medium 8	Medium 7	Low 3	Low 2	Low 1																																																																																																																			
Significant	Medical Treated Injury or illness	On-site release or offsite release immediately contained with smelter resources	High 14	Medium 10	Medium 9	Low 5	Low 4																																																																																																																			
Serious	Lost Time Injury or illness	Off-site release causing nuisance or community complaint. Breach of license condition	High 16	High 15	Medium 12	Medium 11	Low 6																																																																																																																			
Severe	Fatality or Permanently disabling injury of illness	Off-site release with detrimental impact to environment or community. Repeated breach of license conditions	Extreme 24	Extreme 22	High 20	High 18	Medium 13																																																																																																																			
Disastrous	Multiple Fatalities or work-related fatal diseases	Toxic release off-site with detrimental impact to environment or community	Extreme 25	Extreme 23	Extreme 21	High 19	High 17																																																																																																																			
LEGEND			ACTION REQUIRED			NOTIFY																																																																																																																				
LOW 1-6			Tolerable - Manage by Routine Procedures																																																																																																																							
MEDIUM 7-13			Risk reduction required to "As low as Reasonably Practicable" ALARP			Design Team/Engineer																																																																																																																				
HIGH 14-20			Immediate action required to reduce risk. Authorisation required before proceeding on task			CEO																																																																																																																				
EXTREME 21-25			Intolerable. Cease activity until controls in place to reduce risk. Immediate & urgent Senior Management Team action required			CEO																																																																																																																				
MANAGEMENT ACTIONS																																																																																																																										
Comments						Refer to Action Plan																																																																																																																				
Risk Assessment Referred to:						Design Team																																																																																																																				
Risk Assessment Accepted by:						Andrew Melville																																																																																																																				
Risk Assessment findings recorded in the Project Design Folder						Design Team																																																																																																																				
Risk Assessment Findings communicated to:						Design Team, Melville Equipment Corp.																																																																																																																				




Ref no	Description / hazard / risk	Raw Risk Rating (no controls)			Controls	Residual Risk Rating (after controls)			Is Risk Tolerable Y/N	Additional Controls Req	Action By / Name & date required
		Consequence (no controls)	Likelihood	Risk Level & Score		Consequence	Likelihood	Risk Level & Score			
	Manual lifting of machine or segments of machine is dangerous to the operators back, and other areas	Serious	Likely	15	Use of lifting points for machines(crane) to lift the machine. No person to lift any machine at all	Serious	Rare	6	Y	Document lifting points	
	Weight at handles through incorrect trackpack setup causing strain on operator (trackpack only)	Significant	Likely	10	Correctly adjust trackpack pin location. Details shown in manual	Significant	Rare	4	Y	Documented in trackpack manual	
	Fluid levels too high causing overflow and low causing machine damage	Significant	Likely	10	Pre-start checklist requiring operator to check fluid levels before operating machine	Significant	Rare	4	Y	Pre start checklist	
	Exposure to hazardous materials such as fuel and oils	Significant	Likely	10	Hazardous material documentation in MSDS.	Significant	Rare	4	Y	MSDS	
	Fueling the fuel tank can lead to explosions, fires, and dangerous fumes being inhaled	Serious	Possible	12	Engine must only be re-filled when the power pack is stopped and in well ventilated area	Serious	Rare	6	Y		
	Inhalation of exhaust fumes	Significant	Possible	9	Operation in a ventilated area	Significant	Rare	4	Y		
	Injury can occur through connection of quick snap connections	Minor	Possible	3	Must be connected parallel to each other.	Minor	Rare	1	Y		
	General machine operation	Significant	Likely	10	Procedures developed such as prestart checklist	Significant	Rare	4	Y	Pre start checklist	
	Injury through oil injection through hydraulic failure	Serious	Possible	12	Checking of all hydraulics eg Hose's for damage	Serious	Rare	6	Y	Procedure on hose checks	
	Loud noise from engine and machine causing permanent hearing damage	Serious	Likely	15	Manufacturer specifications rate the motor at 94dba at 1m.Motor fitted with muffler. Operator required to wear hearing protection.	Serious	Unlikely	11	Y		



		Raw Risk Rating (no controls)				Residual Risk Rating (after controls)					
Ref no	Description / hazard / risk	Consequence (no controls)	Likelihood	Risk Level & Score	Controls	Consequence	Likelihood	Risk Level & Score	Is Risk Tolerable Y/N	Additional Controls Req	Action By / Name & date required
	Serious burns can occur through the touching of hot surfaces	Significant	Likely	10	Include warning signs. Include warnings in training and operating manuals.	Significant	Unlikely	5	Y	Warning sticker list	
	Battery contains corrosive material. Operator can be exposed to injury from battery acid spills	Serious	Possible	12	Batteries securely mounted. Wear protective clothing when handling battery.	Serious	Rare	6	Y		
	Trip hazard through ballast and loose items on rail way	Significant	Likely	10	Correct training in railway safety	Significant	rare	4	Y	Railway Safety	
	Crushing injury through falling machine if incorrectly supported	Serious	Likely	15	Correctly secured to rail trolley and powerpack (if applicable)	Serious	Rare	6	Y		
	Pinch points exist through the connection of power pack to trolley and powerpack to work head	Significant	Possible	9	Procedure shown on connection of powerpack, trolley, and work head. Gloves to be worn	Significant	Unlikely	5	Y	procedure shown in connection of items	
	Injury through crushing during clip extraction	Serious	Possible	9	Guarding of moving parts and pinch points,	Serious	Rare	6	Y		
	Injury through Kicking/jerking of machine under incorrect alignment	Minor	Likely	7	Correct training in machine use through manual. Use of correct head alignment spacers for rail height	Minor	Unlikely	2	Y		
	Injury of crushing through Workhead being in engaged position	Serious	Likely	15	Correct training of operation of machine. Handle spring loaded to leave machine in neutral position	Serious	Rare	6	Y		
	Pinch points exist on workhead's swiveling foot	Significant	Likely	10	Correct operation procedures.	Significant	Rare	4	Y		



13.2. 108 Spike Puller Hydraulic circuit diagram





13.3. MEC Base Level Head (Main Parts)

NOTES



SKOTCH KEY PISTON
TO PISTON LOCK NUT

C	29	1	5/16" SPRING WASHER	SW05
	28	2	SEL LOK PIN 3/16in x 1-1/4in	R18732
	27	1	BACK UP WASHER 3-1/8" x 3-1/2"	OR8338
	26	1	ORING 3-1/8" x 3-1/2" x 3/16" CS	OR2338
	25	1	O RING	OR2222
	24	1	NUT 1-1/4" UNF HALF NYLOC	N20NFINH
	23	1	H082 + MCJF-1408 + 00302 + MCJF90M-01408	H082-00400-005
	22	1	GRUB SCREW M8 x 10	GRSM0810
	21	2	GRUB SCREW 3/8" UNC x 3/8" LG	GRSC0606
	20	1	ELBOW 90 M/M 3/8"BSPT x 7/8"JIC	CB56-0614
	19	1	BOLT METRIC M8 x 16LG ZINC GR8.8	BM0816
	18	2	CLEVIS LOCK COPPER SCREW THREAD	1081237
	17	1	PISTON ROD 8T	1081224
D	16	1	JAW PIVOT ASSEMBLY	1080508
	15	2	JAWS DOG SPIKE JAWS	1080507
	14	2	JAWS-LOCK SPIKE	1080506
	13	2	JAW SPIKE RELEASE CAMS	1080505
	12	1	SPIKE PULLER CLEVIS PIN	1080502
	11	1	SPIKE PULLER CLEVIS	1080501
	10	1	PISTON SEAL 8T	1080311
	9	1	PISTON LOCKNUT	1080309
	8	1	PISTON 8T	1080306
	7	1	VALVE HEAD ASSEMBLY	1080098
	6	1	GLAND LOCKNUT-3.5DIA CYL 8T AND BOLT	1080049
	5	1	CYLINDER 3.5ID MODEL 8T	1080045
	4	1	GLAND BODY-MODEL 8T	1080041
3	1	U CUP GLAND SEAL	1080037	
2	1	GLAND ROD WIPER 1.5DIA	1080035	
1	3	CYLINDER RAIL HEIGHT ADJUST RINGS	1080016	

ITEM	QTY	DESCRIPTION	PART NUMBER
MATERIAL/CUT LIST			




5	18/2/2014	GM	REMOVED FOOT. ADDED TO TOP LEVEL AS QRF38
4	15/7/11	GM	CHANGED TO SELF LEVELLING HEAD AS QRF34
3	21/10/2010	GM	MOVED TO INVENTOR DRAWING
2	5/3/2008	KH	CLOSED BOTTOM OF VALVE HEAD AND REMOVED BRONZE BUSH
1			ADDED QUICK CHANGE BOOM MOUNT
UNO	01/10/2010		ORIGINAL ISSUE


Melville Equipment Corp. Pty. Ltd		DIMENSIONS IN mm UNO		0	21/10/2010	ADDED QUICK CHANGE BOOM MOUNT		
		TOLERANCES UNO		REV	DATE	DRN	ORIGINAL ISSUE	
 8 Rogilla Close Walsford N.S.W. 2287 Ph: +61 61 4951 5244 Fax: +61 61 4950 1291		.XX ±0.1		XXX ±0.2		DESCRIPTION	PART #	
		.XXX ±0.2		XXX ±0.3		SPIKE PULLER HEAD 8T ONLY 3.5" CYL- NO MOUNTING BRACKET		FP-108-BK
		.X ±0.2		X ⁰ ±0.1 ⁰				
		.X ±0.5		X ⁰ ±0.5 ⁰				
		.XX ±0.1		.X ±0.5		DRAWN		DATE
		garyM		21/10/2010		garyM		
		CHECKED		APPROVED		SCALE	2-108-101 REV 5	
		AGS		AGS				
This drawing and the contents within are the property of Melville Equipment Corp. Pty. Ltd.								




13.4. Honda Petrol Recoil Start Dedicated Machine



13.5. Honda Petrol Electric Start Dedicated Machine



13.6. Yanmar Diesel Electric Start Dedicated Machine



54	1	SPIKE PULLER JAW HOUSING ASSY SELF LEVELLING	1080557
42	3	TEK SCREW TAPTITE - RESERVOIR BREATHER	TAPTIT1
41	4	3/8" SPRING WASHER	SW06
40	8	5/16" SPRING WASHER	SW05
39	7	1/4" SPRING WASHER	SW045Q
38	4	SOCKET HEAD CAP SCREW M8 x 30	SHM0830
37	4	SOCKET HEAD CAP SCREW M8 x 20	SHM0820
36	4	SOCKET HEAD CAP SCREW M6 x 25	SHM0625
35	4	SOCKET HEAD CAP SCREW 1/4" UNC X 1-1/4" LG	SHCD420
34	2	SOCKET HEAD CAP SCREW 1/4" UNC X 3/4"	SHCD412
33	2	NUT M6 NYLOC	NM06N
32	4	NUT 3/8" UNC BLACK	N06NC
31	6	NUT 1/4" UNC NYLOC	N04NCN
30	4	FLAT WASHER - ENGINEERS - 3/8" X 3/4" ZINC	FW06
29	10	FLAT WASHER - ENGINEERS - 1/4" X 1/2" ZINC	FW0408
28	1	SPIKE PULLER HEAD BT ONLY-3.5" CYL	FP-108-BK
27	1	WIRING HARNESS YANMAR 108/143DEDICATED MACHINE	ESTOP05
26	1	PLUG 1/2"BSPP	CP77-08
25	1	NIPPLE 1/2"BSPP - 1-1/16"JIC	CP2-0817
24	4	NIPPLE 1/2"BSPP X 7/8" JIC	CP2-0814
23	1	TUBE ASS SHORT 90 F/M 1-1/16"JIC	CP3-1717
22	1	HOSETAIL 90 3/4"UNO X 3/4"HOSE	CG0-1212
21	2	BOLT M6 x 90 GRADE 8.8 ZINC	BM0690Z
20	4	BOLT HT 3/8" UNC X 1-3/4"	BO0628
19	1	BATTERY 12V SEALED 120AH DEKA	1540412
18	1	YANMAR ENGINE L70ADEE ELECTRICSTART ENGINE	1540210
17	1	FILTER AND KICKDOWN BRACKET	1450273
16	1	BATTERY BOX TOP CLAMP	1430113
15	1	PUMP 7.8-7.9cc GROUP 1	1430081
14	1	BELL HOUSING - GROUP 1&2 7-18HP ENGINES FEMALE	1110023
13	1	SPIKE PULLER DEDICATED MP FILTER ASSEMBLY	1081286
12	1	HOSE CLAMP DOUBLE 22mm - BOLT GROUP 3 CLAMPS	1081101-04
11	1	HOSE CLAMP DOUBLE 22mm - TOP PLATE GROUP 3	1081101-03
10	2	HOSE CLAMP DOUBLE 22mm - JAWS	1081101-01
9	1	8 LITRE RESERVOIR COMPLETE	1081000
8	1	BATTERY BOX SUIT DEKA BATTERY	1080864
7	1	KICKDOWN VALVE ASSEMBLY INCLUDING LOGO	1080847
6	1	HOSE CLAMP 14-32 SCREW TYPE	1080722
5	1	ENGINE COUPLING RUBBER SPIDER 65 SERIES	1080710
4	1	PUMP COUPLING - GROUP 1 65 SERIES	1080709
3	1	ENGINE HALF COUPLING - 1 SHAFT 65 SERIES	1080708
2	1	ROLL BAR BOOM ASSY 7-11HP WITH ENGINE RAIL ELECTRIC START	1080702
1	1	PUMP HEAT GASKET - GRP 1	1080058
ITEM	QTY	DESCRIPTION	PART NUMBER
MATERIAL/CUT LIST			

2	14/01/2012	AG	CHANGED FILTER AS PER CIP 532
1	21/03/2012	AG	REVISED MP FILTER
1	22/04/2013	GMM	ORIGINAL 1550M
REV	DATE	DRN	DESCRIPTION
DESCRIPTION	PART #		
SPIKE PULLER 7 HP	FP-108-EE		
YANMAR ELECTRIC			
START NO LIGHT			
MODELLER BY	GMM		
DRAWN	DATE		
14/01/2012			
CHECKED	APPROVED	SCALE	1:1
1-108-204			
2			
This drawing and the contents herein are the property of Mahindra Equipment Corp. Pvt. Ltd. If in doubt, ask!			



13.7. FP-108-YE - Yanmar Diesel Electric Start Dedicated Machine

1 OF 5		FIT DETAIL		2	3	4	5	6
SHEET #		SHEET DESCRIPTION						
73	NUT 1/4 UNC NYLOC		N04NCN	2				
72	HOSE END MEGA CRIMP FEMALE - 1-1/16"JIC X 3/4"HOSE		MCJF-1712	2				
71	HOSE END MEGA CRIMP FEMALE - 7-8 JIC X 3-4 HOSE		MCJF-1412	1				
70	HOSE END MEGA CRIMP FEMALE - 7/8"JIC X 1/2"HOSE		MCJF-1408	4				
69	HOSE END MEGA CRIMP FEMALE - 9/16"JIC X 1/4"HOSE		MCJF-0904	1				
68	HOSE END MEGA CRIMP FEMALE 90 -1-1/16"JIC X 3/4"HOSE		MCJF90S-1712	2				
67	HOSE END MEGA CRIMP FEMALE 90 - 7/8"JIC X 1/2"HOSE		MCJF90S-1408	1				
66	HOSE END MEGA CRIMP FEMALE 90 - 9/16"JIC X 1/4"HOSE		MCJF90S-0904	1				
65	HOSE END MEGA CRIMP FEMALE 90 - 7/8"JIC X 1/2"HOSE		MCJF90M-1408	1				
64	LARGE MELVELLE UPRIGHT		LAB0030	1				
63	PPE SAFETY STICKER		LAB0008	1				
62	MELVELLE ACHIEVING EXCELLENCE STICKER		LAB0004	1				
61	ESTOP WARNING LABEL REVERSED		IDTAG12	1				
60	MELVELLE MODEL & SERIAL N-O AL TAG		IDTAG02	1				
59	MELVELLE AUSTRALIA IDENTIFICATION TAG		IDTAG01	1				
58	RAIL HEIGHT SPACER TAG		IDRLHEI	1				
57	H042 + MCJF-0904 + 01941 + MCBM-0604		H042-02000-008	1				
56	FLAT WASHER - ENGINEERS - M4		FWM04	2				
55	FLAT WASHER - ENGINEERS - 1/4" X 1/2" ZINC		FW0408	8				
54	FLAT WASHER - ENGINEERS - 1/2" X 1" ZINC		FW08	6				
53	FLAT WASHER - ENGINEERS - 3/8" X 3/4" ZINC		FW06	4				
52	FLAT WASHER - ENGINEERS - 5/16" X 5/8" ZINC		FW05	7				
51	SPIKE PULLER HEAD DUAL HANDLE -8T - NO BRACKET		FP-108-BK-DT	1				
50	PILOT LED, GREEN, 12V, IP40, 16mm PANEL MOUNT		ELECT228	1				
49	PILOT LED, RED, 12V, IP40, 16mm PANEL MOUNT		ELECT227	1				
48	LS3 LIMIT SWITCH		ELECT100	1				
47	EMERGENCY STOP ENCLOSURE AND BUTTON - YELLOW		ELECT69	1				
46	COUNTER SUNK CAP SCREW M4 x 35 ZINC		CSM0435Z	2				
45	PLUG 3/8"BSPP		CP77-06	1				
44	ELBOW 90 MM 3/8"BSPP X 9/16"JIC		CP56-0609	1				
43	NIPPLE 1/2"BSPP - 1-1/16"JIC		CP2-0817	2				
42	NIPPLE 1/2" BSPP X 7/8" JIC		CP2-0814	4				
41	NIPPLE 1/4" BSPP X 9/16" JIC		CP2-0409	1				
40	TUBE ASS SHORT 90 F/M 1-1/16"JIC		C93-1717	1				
39	BOLT METRIC M8 x 30 ZINC GR8.8		BM08030-88Z	7				
38	BOLT METRIC M12 X 55 LG ZINC GR8.8		BM1255-88Z	2				
37	BOLT HT M12 X 50		BM1250	2				
36	BOLT M12 x 45 ZP HT		BM1245Z	2				
35	BOLT M6 x 20 HT		BM0620	2				
34	BOLT HT 3/8" UNC X 1-3/4"		BC0628	4				
33	CONTROL CABLE ACTUATOR - TRIGGER END ASS		1860120	2				
32	CLIPPER BRAKE TRIGGER ASSEMBLY		1860113	1				
31	HANDLE LOCKING PIN		1860027	1				
30	TOP HANDLE FABRICATION		1860024	1				
29	REMOTE CONTROL TRIGGER-M10		1640035	2				
28	LOCKOUT ISOLATER MOUNT PLATE		1560166	1				
27	OIL PRESSURE SWITCH - 1/8TH BSP X 10 PSI		1540816	1				
26	BATTERY ISOLATOR SWITCH - INCLUDING RED LOCKOUT		1540813	1				
25	BATTERY 12V SEALED 120AH DEKA		1540412	1				
24	YANMAR ENGINE L70N6 ELECTRIC START ENGINE		1540210	1				
23	TEE BOLT LOCKING NUT		1450284	1				
22	1/2" TEE LOCKING BOLT 2" LONG		1450283	1				
21	CONTROL CABLE END CAP MOUNTS TO 1450165		1450166	2				
20	BRAKE MANIFOLD - ELECTRIC SOLENOID		1430119	1				
19	BATTERY BOX TOP CLAMP		1430113	1				
18	PUMP 7.8-7.9cc GROUP 1		1430081	1				
17	BELL HOUSING - GROUP 1&2 7-18HP ENGINES FEMALE		1110023	1				
16	FILTER MOUNTING BRACKET		1081466	1				
15	ROLL BOOM ASSY WITH 7HP YANMAR ELECTRIC START		1081465	1				
14	SWIVEL FOOT JAW HOUSING SPACER PROFILE		1081400-01	2				
13	CABLE GUARD FOR THIN CABLES		1081369	2				
12	CABLE ADAPTER TRIGGER TO CABLE		1081364	2				
11	BASE HANDLE EXTENSION SPIKE PULLER		1081325	1				
10	SPIKE PULLER DEDICATED MP FILTER ASSEMBLY		1081286	1				
9	8 LITRE RESERVOIR COMPLETE		1081000	1				
8	BATTERY BOX SUIT DEKA BATTERY		1080864	1				
7	HOSE CLAMP 14-32 SCREW TYPE		1080722	1				
6	ENGINE COUPLING RUBBER SPIDER 65 SERIES		1080710	1				
5	PUMP COUPLING - GROUP 1 65 SERIES		1080709	1				
4	ENGINE HALF COUPLING - 1 SHAFT 65 SERIES		1080708	1				
3	JAW HOUSING ASSEMBLY- SWIVEL FOOT STYLE		1080500	1				
2	PUMP HEAT GASKET - GRP 1		1080058	1				
1	MALE 3/8" FLUSH FACED SNAP CONNECTOR		1020342	1				
ITEM	DESCRIPTION	PART NUMBER	ITEM QTY	ITEM	DESCRIPTION	PART NUMBER	ITEM QTY	
PARTS LIST				PARTS LIST				


0	28/10/2021	-	-	ORIGINAL ISSUE	-	-
REV	DATE	DRN	CRF	DESCRIPTION	CHK	APP
TOLERANCES UNO:-				DIMENSIONS IN mm UNO		
.XX ±0.1	XXX. ±2.0	DESCRIPTION				PART #
.X ±0.2	XXX. ±3.0					
.X ±0.5	X° ±0.1°					
XX ±1.0	X° ±0.5°	SPIKE PULLER 7HP				FP-108-YE
YANMAR ELECTRIC						
START WITH BRAKES				MODELLER BY		
				garym		
DRAWN	DATE	SCALE				2-108-567
BenH	28/10/2021	1:1				0
CHECKED	APPROVED					
BB	BB					


10 Rogilla Close
Wallsend N.S.W 2287
Ph: +61 02 4951 5244
Fax: +61 02 4950 1291


IF IN DOUBT, ASK!


This drawing and the contents within are the property of Melville Equipment Corp. Pty. Ltd.
It is not to be copied, distributed or used in any other manner.












0	28/10/2021	-	-	ORIGINAL ISSUE	-	-
REV	DATE	DRN	CRF	DESCRIPTION	CHK	APP
TOLERANCES UNO:-						
.XX ±0.1	XXX. ±2.0	DIMENSIONS IN mm UNO				
.X ±0.2	XXXX. ±3.0					
X ±0.5	X° ±0.1°					
XX ±1.0	X° ±0.5°					
DRAWN	DATE	SCALE				
BenH	28/10/2021					
CHECKED	APPROVED					
BB	BB					
1:5				2-108-567		
IF IN DOUBT, ASK!				REV 0		

13.8. MEC Backpack Head



13.9. Trolley to Power Pack Attachment

1. PLACE TROLLEY ONTO RAIL

2. LIFT POWERPACK AND WORKHEAD BY LIFTING EYE AS SHOWN

3. ROTATE CROSS TROLLEY UNTIL SQUARE WITH BOOM

4. SLOWLY LOWER THE ASSEMBLY DOWN AND MOVE THE BASE


TROLLEY TO LINE UP WITH THE CROSS TROLLEY.

NOTE: DO NOT ATTEMPT TO ROTATE THE CROSS TROLLEY WHILE

MACHINE IS BEING LOWERED.

NOTE


*SAME LIFTING PROCEDURE USED
REGARDLESS OF WORKHEAD BEING USED
* WHEN LIFTING COMBINE WORKHEAD
AND TRACKPACK LIFT FROM CENTER EYE
ONLY (ENSURE BOOM PIN IS SECURED)



1	26/04/2017	BB	-	UPDATED TO CURRENT EQUIPMENT		
REV	DATE	DRN	CRF	DESCRIPTION	CHK	APP
DIMENSIONS IN mm UNO				0	2/04/2012	GMM ORIGINAL ISSUE
TOLERANCES UNO:-				REV	DATE	DRN
XX ±0.1	XXX ±2.0	DESCRIPTION				PART #
X ±0.2	XXXX ±3.0	TROLLEY TO POWERPACK ATTACHMENT				---
X ±0.5	X° ±0.1°					MODELLED BY
XX ±1.0	X° ±0.5°					garm
DRAWN	DATE	SCALE				1
garm	2/04/2012	1:8				
CHECKED	APPROVED	3-108-215				REV
IF IN DOUBT, ASK!				This drawing and the contents within are the property of Melville Equipment Corp. Pty. Ltd. It is not to be copied, distributed or used in any other manner.		




13.10. Track pack head with swivel foot



13.11. Lower level Track pack head dual handle


NOTES
SKOTCH KEY PISTON
TO PISTON LOCK NUT




37	1	5/16" SPRING WASHER	SW05
36	2	SEL LOK PIN 3/16in x 1-1/4in	R18732
35	1	BACK UP WASHER 3-1/8" x 3-1/2"	OR8338
34	1	ORING 3-1/8" x 3-1/2" x 3/16" CS	OR2338
33	1	O RING	OR2222
32	1	NUT 1-1/4" UNF HALF NYLOC	N20NFNH
31	1	H082 + MCJF-1408 + 00210 + MCJF905-1408	H082-00310-004
30	1	GRUB SCREW M8 x 10	GRSM0810
29	2	GRUB SCREW 3/8" UNC x 3/8" LG	GRSC0606
28	1	PLUG 3/4" BSPP	CP77-12
27	1	NIPPLE 3/4" BSPP X 7/8" JIC	CP2-1214
26	2	NIPPLE 1/2" BSPP X 7/8" JIC	CP2-0814
25	1	ELBOW 90 M/M 3/8"BSPT X 7/8"JIC	CB56-0614
24	1	BOLT METRIC M8 X 16LG ZINC GR8.8	BM0816
23	1	TEST POINT COUPLING 1/4"BSPP	1860034
22	1	SPIKE PULLER DUAL HANDLE MANIFOLD	1081368
21	1	CYLINDER CLAMP BRACKET SPIKE PULLER	1081326
20	2	CLEVIS LOCK COPPER SCREW THREAD	1081237
19	1	PISTON ROD 8T	1081224
18	1	JAW PIVOT ASSEMBLY	1080508
17	2	JAWS DOG SPIKE JAWS	1080507
16	2	JAWS-LOCK SPIKE	1080506
15	2	JAW SPIKE RELEASE CAMS	1080505
14	1	SPIKE PULLER CLEVIS PIN	1080502
13	1	SPIKE PULLER CLEVIS	1080501
12	1	PISTON SEAL 8T	1080311
11	1	PISTON LOCKNUT	1080309
10	1	PISTON 8T	1080306
9	1	VALVE HEAD CYLINDER BACK UP RING	1080125
8	1	VALVE HEAD CYLINDER O RING	1080124
7	1	GLAND LOCKNUT-3.5DIA CYL 8T AND BOLT	1080049
6	1	CYLINDER 3.5ID MODEL 8T NO GROOVE	1080045-NG
5	1	GLAND BODY-MODEL 8T	1080041
4	1	U CUP GLAND SEAL	1080037
3	1	GLAND ROD WIPER 1.5DIA	1080035
2	3	CYLINDER RAIL HEIGHT ADJUST RINGS	1080016
1	1	CYLINDER CAP NUT	1080009


ITEM QTY DESCRIPTION PART NUMBER

PARTS LIST





1	7/07/2017	BB	1418	CHANGED HOSE END FROM MCJF90M	BMD	EMD
0	21/07/2015	GM	-	ORIGINAL ISSUE	CHK	APP
REV	DATE	DRN	CRF	DESCRIPTION		
TOLERANCES UNO:-				DIMENSIONS IN mm UNO		
XX	±0.1	XXX	±2.0	DESCRIPTION	PART #	
X	±0.2	XXX	±3.0	SPIKE PULLER HEAD	FP-108-BK-DT	
X	±0.5	X°	±0.1°	DUAL TRIGGER - 8T CYL-	MODELLED BY	
XX	±1.0	X°	±0.5°	NO MOUNTING BRACKET	garyM	
DRAWN	DATE			SCALE		
garym	20/07/2015			1:3		
CHECKED	APPROVED			2-108-389 1		




10 Rogilla Close
Wallbend N.S.W 2287
Ph: +61 02 4951 5244
Fax: +61 02 4950 1291
IF IN DOUBT, ASK!

This drawing and the contents within are the property of Melville Equipment Corp. Pty. Ltd.
It is not to be copied, distributed or used in any other manner.


Operation Manual | FP-108
Version: 1.2

55

13.12. Track pack head sliding leg housing




13.13. Hydraulic circuit diagram dual trigger manifold





NOTES - TO SET PRESSURES

- 1) ALL PRESSURE SETTINGS WILL BE MEASURED FROM TEST POINT TP-P. A ELECTRONIC PRESSURE GAUGE WITH MAXIMUM PRESSURE RECALL IS RECOMMENDED.
- 2) TURN RQEB IN UNTIL MAXIMUM PRESSURE WILL BE ACHIEVED. SQUEEZE THE LEFT TRIGGER AND SET RVBA TO 190 BAR. NOTE THE ENGINE MAY WANT TO STALL AT THIS PRESSURE, RESET THE LEFT TRIGGER TO ALLOW THIS PRESSURE TO BE REACHED.
- 3) NEXT SET RQEB. FIRST TURN THE VALVE OUT A FEW TURNS THEN BEGIN TO SET BY SQUEEZING THE LEFT TRIGGER AND WATCHING THE PRESSURE RISE QUICKLY. CONTINUALLY RESET THE LEFT TRIGGER WHILE TURNING IN RQEB UNTIL THE VALVE IS UNLOADING AT 183 BAR.
- 4) TO SET RDDB SQUEEZE THE LEFT HAND TRIGGER UNTIL THE SYSTEM UNLOADS AND IS SITTING UNDER THE RELIEF PRESSURE, SET THIS VALVE TO 55 BAR.
- 5) ALL VALVES SHOULD NOW BE SET. BY SQUEEZING THE LEFT TRIGGER, THEN OPERATING THE RIGHT TRIGGER ENSURE THE CYLINDER EXTENDS AND RETRACTS FREELY.

 <p>Melville Equipment Corp. Pty. Ltd.</p> <p>8 Rogilla Close Wallsend N.S.W. 2287 Ph: +61 02 4951 5244 Fax: +61 02 4950 1291</p> <p>IF IN DOUBT, ASK!</p>	DIMENSIONS IN mm UNO		0	31/07/2015	GM	ORIGINAL ISSUE
	TOLERANCES UNO:-		REV	DATE	DRN	DESCRIPTION
	.XX ±0.1	XXX. ±2.0	108 SPIKE PULLER HYDRAULIC CIRCUIT DIAGRAM			
	.X ±0.2	XXXX. ±3.0				
DRAWN		DATE		PART#		
GM		31/07/2015		FP-108-TP/F		
CHECKED		APPROVED		AUTOCAD		
BMD		BMD		DRAWING		
		NTS		3-108-393		
				REV 0		

13.14. Trackpack Boom Adjustment



Melville Equipment Corp.
Pty. Ltd

8 Rogilla Close
Wallsend N.S.W 2287
Ph: +61 02 4951 5244
Fax: +61 02 4950 1291
IF IN DOUBT, ASK!

1	31/03/2016	GM	-	ADDED 186-EYE AND 190	BMD	BMD
REV	DATE	DRN	CRF	DESCRIPTION	CHK	APP
DIMENSIONS IN mm UNO				0	2/04/2012	GMM ORIGINAL ISSUE
TOLERANCES UNO:-				REV	DATE	DRN DESCRIPTION
.XX ±0.1	XXX. ±2.0	DESCRIPTION		PART #		
.X ±0.2	XXXX. ±3.0	OLD STYLE TRACKPACK BOOM ADJUSTMENT (PRE APRIL 2017)		MODELLED BY GaryM		
X. ±0.5	.X° ±0.1°					
XX. ±1.0	X.° ±0.5°					
DRAWN	DATE	SCALE		3-143-48 REV 1		
garym	2/04/2012	1:4				
CHECKED	APPROVED	SCALE				
		1:4				