Melvelle Equipment Corp Pty Ltd

"Proud Australian Manufacturers"



190 E-Clip & PR Clip

Inserter/Remover

Operation, Training & Maintenance Manual



P: +61 2 4951 5244

E:sales@melvelle.com.au W: www.melvelle.com.au

	Melvelle Equipm	ent Corp Pty Ltd	
	Address:	10 Rogilla Close	
		MARYLAND NSW 2287	
		AUSTRALIA	
	Phone: 61 2 49 515 224	Fax: 61 2 49 501 291	
Notes:	Email: <u>sales@melvelle.com.au</u>	Web: <u>www.melvele.com.au</u>	
•••••			
•••••			
			•••••
			•••••
			<u>.</u>
			.,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
			,
		1	

Current Edition: 1.15

Updated Date: 1st September 2022

Table of Contents

TABLE OF CONTENTS			
1.	PF	REFACE	6
2.	SA	AFETY INFORMATION	7
3.	SA	AFETY SYMBOLS	8
2.21	0,		
3.1	•	SAFE IY SYMBOLS & SIGNAL WORDS	ه و
3.3		PERSONAL PROTECTION SYMBOLS	. 12
3.4		PROHIBITION SYMBOLS	.13
Д	S۵		14
ч. г	5/		20
5.	EC	QUIPMENT STICKERS & TAGS	. 20
1	5.1.	Stickers & Tags Locations	. 23
6.	ΕN	MERGENCY STOP	. 25
7.	IN	TRODUCTION	.26
8	SD	PECIFICATIONS	28
0.	51		. 20
8.1	•	FP-190-TP-TRACKPACK WORKHEAD	.28
ð.2	•	FP-190-IP-02A - TRACKPACK WORKHEAD	. 28
9.	O	PERATION	. 29
9.1		OPERATING CONDITIONS	. 29
9.2	•	PRE-OPERATION CHECKS	. 30
9.3	•	ASSEMBLY PROCEDURES	. 32
9	9.3.1	. Braked Machine Trolley	. 32
<u>(</u>	9.3.2	. Machine Assembly – Trackpack	. 32
<u>(</u>	9.3.3	. Handle Adjustment	. 35
9	9.3.4	. Machine Adjustment – Workhead Angle	. 36
9	9.3.5	. Machine Adjustment – Shoulder to Shoulder spacing	. 37
9.4	•	JAW ASSEMBLY	.41
9	9.4.1	. Concrete Sleeper, E-clip – Clipping Up	. 41
9	9.4.2	Concrete Sleeper, E-clip – Unclipping	. 41
<u>c</u>	9.4.3	One sided Operation	. 42
9	9.4.4	. Timber/Composite Sleeper Terminology	. 44
9	9.4.5	Clip Style Terminology – E-Clip/ PR-Clip	. 44
9	9.4.6	. Timber/Composite Sleeper Plate Variations	. 45
9	9.4.7	. Special Track Plates	. 47
9	9.4.8	. Timber/Composite Sleeper Cast Plate, E-clip – Clipping Up	. 48
<u>(</u>	9.4.9	. Timber/Composite Sleeper, Cast Plate, E-clip – Unclipping	. 49
<u>(</u>	9.4.1	0. Timber/Composite, Rolled Plate, E-clip – Clipping Up	. 50
9	9.4.1	1. Timber/Composite, Rolled Plate, E-clip – Unclipping	. 51
9.5		OPERATION PROCEDURES	. 52
9	9.5.1	. Starting the Engine – Electric Start	. 52
9	9.5.2	. Starting the Engine – Recoil Start	. 53
9	9.5.3	. Equipment Operation – Releasing the Brake	. 54
<u>c</u>	9.5.4	Equipment Operation – Un-Clipping	. 55
9	9.5.5	. Equipment Operation – Clipping	. 58
9	9.5.6	. Stopping the Engine	. 60

10.	DIS	ASSEMBLY PROCEDURES	61
	10.1.	Removal of Machine from Track	61
	10.2.	Lifting the Machinery	63
11.	STC	RAGE & TRANSPORT	64
	11.1.	Storage of E-Clip Machine	64
	11.2.	Fitting work head to stowage frame	64
	11.3.	Transport of E-Clip Machine – Work head only	65
12.	EQI	JIPMENT PROTECTION & CARE	66
13.	MA	INTENANCE	67
	13.2.	Maintenance Period	68
14.	TRC	DUBLESHOOTING	70
15.	APF	PENDIX A – PR CLIP JAWS	73
	15.1.	Concrete Sleeper, PR-clip – Clipping Up	73
	15.2.	Concrete Sleeper, PR-clip - Unclipping	73
	15.3.	Timber/Composite Sleeper, Cast Plate, PR-clip – Clipping Up	74
	15.4.	Timber/Composite Sleeper, Cast Plate, PR-clip – Unclipping	75
	15.5.	Timber/Composite Sleeper, Rolled Plate, PR-clip – Clipping Up	76
	15.6.	Timber/Composite Sleeper, Rolled Plate, PR-clip – Unclipping	77
	15.7.	Steel Sleeper 80lb.C.R. , PR-clip – Unclipping and Un clipping	78
16.	APF	PENDIX B – 150MM (6") SLEEPER PLATE E-CLIP JAWS	79
	16.1.	Timber/Composite Sleeper 150mm (6") Cast Plate, E-clip – Clipping Up	79
	16.2.	Timber/Composite Sleeper, 150mm (6") Cast Plate, E-clip – Unclipping	80
	16.3.	Timber/Composite, 150mm (6") Rolled Plate, E-clip – Clipping Up	81
	16.4.	Timber/Composite, 150mm (6") Rolled Plate, E-clip – Unclipping	82
17.	APF	PENDIX C – 216MM (8.5") SLEEPER PLATE E-CLIP JAWS	83
	17.1.1.	Timber/Composite Sleeper 216mm (8.5") Cast Plate, E-clip – Clipping Up	83
	17.1.2.	Timber/Composite Sleeper, 216mm (8.5") Cast Plate, E-clip – Unclipping	
	17.1.3.	Timber/Composite, 216mm (8.5") Rolled Plate, E-clip – Clipping Up	85
	17.1.4.	Timber/Composite, 216mm (8.5") Rolled Plate, E-clip – Unclipping	
18.	APF	PENDIX D – 16" VICTOR PLATE E-CLIP JAWS	87
	18.1.	Timber/Composite Sleeper 16" Victor Plate, E-clip – Clipping Up	
	18.2.	Timber/Composite Sleeper 16" Victor Plate, E-clip – Un-Clipping	
19.	APF	PENDIX E - 18" VICTOR PLATE E-CLIP JAWS	
	19.1.	Timber/Composite Sleeper 18" Victor Plate, E-clip – Clipping Up	
	19.2.	Timber/Composite Sleeper 18" Victor Plate, E-clip – Un-Clipping	90
20.	APF	PENDIX F - PANDROL 91533 RAIL PLATE	91
	20.1.	Timber/Composite Sleeper, Pandrol 91533 Rail Plate, E-clip – Clipping Up	91
	20.2.	Timber/Composite Sleeper, Pandrol 91533 Rail Plate, E-clip – Un Clipping	92
21.	APF	PENDIX G – DELKOR RAIL EGG RF167 & RF127 (ELASTIC RAIL FASTENER)	93
	21.1.	Concrete Slab Track Sleeper, Delkor RF167, E-clip – Clippina Up	
	21.2.	Concrete Slab Track Sleeper, Delkor RF167, E-clip – Un Clippina	
	21.3.	Concrete Slab Track Sleeper, Delkor RF127, E-clip – Clipping Up & Un Clipping	

22.	APF	PENDIX H – LB-FOSTER RUBBER ENCAPSULATED PLATE. STOCK 01-64-3331	95
	22.1.	Clipping Up, Standard E-clips	
	22.2.	Unclipping, standard E-clips	96
23.	APF	PENDIX I – RF-A PLATE. STOCK 01-64-3342 & 01-64-3344	97
	23.1.	Clipping Up, standard E-clips	97
	23.2.	Unclipping, standard E-clips	
	23.3.	Clipping up, Heavy duty/PR clips	
	23.4.	Unclipping, Heavy duty PR clips	
24.	APF	PENDIX J – RF-D PLATE WITH CHECK RAIL. STOCK 01-64-3347	100
	24.1.	100-8lb Rail set up frame as below	
	24.2.	115lb Rail set up frame as below	
	24.3.	Clipping Up – Heavy duty PR-Clip	
	24.4.	Clipping Up – Standard E-Clip	
	24.5.	Unclipping – Heavy duty PR-Clip	
	24.6.	Unclipping – Standard E-Clip	
25.	APF	PENDIX K – NEW YORK CONCRETE SLEEPER	105
	25.1.	Clipping up Standard E-clip	
	25.2.	Unclipping Standard E-clip	
	25.3.	Clipping up Heavy duty PR-clip	
	25.4.	Unclipping Heavy duty PR-clip	
26.	APF	PENDIX L – DELKOR RAIL RF506-02 (ELASTIC RAIL FASTENER)	107
	26.1.	Concrete Slab Track Sleeper, Delkor RF506-02, E-clip – Clipping Up	
	26.2.	Concrete Slab Track Sleeper, Delkor RF506-02, E-clip – Un Clipping	
27.	FUF	RTHER DOCUMENTS	109
2	7.1. J <i>i</i>	AW SELECTION GUIDE	
2	7.2. D	RAWINGS, DIAGRAMS AND RISK ASSESSMENT	
	27.2.1.	Operational Risk Assessment	
	27.2.2.	Trolley to Power Pack Attachment	
	27.2.3.	Trackpack Boom Adjustment (Old Version – Pre April 2017)	119
	27.2.4.	Trackpack Boom Adjustment (Current Version – Post April 2017)	
	27.2.5.	Trackpack Head Assembly Drawing	
	27.2.6.	Hydraulic Circuit Diagram	124
	27.2.7.	Electric Circuit diagram	125
	27.2.8.	Trackpack Head Assembly Drawing - Imperial Version (USA)	126

1. Preface

Every attempt has been made to present accurate and current information within this manual. However, as product development on the 190 work head and components used within is continuous, the information contained herein may be subject to change without notice, and without incurring obligation.

The information provided within this manual is the sole property of Melvelle Equipment Corporation Pty Ltd (MEC) and as such, reproduction or replication of any material contained within is not allowed without the written consent of MEC.

Information provided within this manual assumes:

- The person(s) operating the machinery have read and understand this manual and other manuals provided for specific components
- The person(s) operating are properly trained and equipped to safely and professionally operate this machinery
- The person(s) operating utilise the correct attachments and/or tools, and are trained and equipped to use them safely and professionally

SERVICING THE 190 E & PR CLIP INSERTER/REMOVER

This manual contains safety, operation and periodic maintenance instructions. MEC recommends that servicing of equipment, other than periodic maintenance, must be performed by MEC or certified and authorised dealer. Please read the following warning.



SERIOUS INJURY OR DEATH COULD RESULT FROM THE IMPROPER REPAIR OR SERVICE OF THIS EQUIPMENT.

REPAIRS AND / OR SERVICE OF THIS EQUIPMENT MUST ONLY BE PERFORMED BY MELVELLE EQUIPMENT CORP. PTY LTD. OR CERTIFIED AND AUTHORISED DEALER.

THE USER SHALL NOT MODIFY THE DESIGN OR CONFIGURATION OF EQUIPMENT WITHOUT CONSULTING MEC

2. Safety Information

This operation and training manual is intended to complement existing site procedures.

The following site documentation must be reviewed by the trainee before commencing training:

- Safe Work Procedures (SWP)
- Isolation Procedures

If the training package information conflicts with existing site documentation, then the authorised site and/or end user is to consult with MEC in regards to any possible amendments or modifications required.

The following practices and procedures must be adhered to:

- Always complete Pre-Operation Checks prior to use and report any defects if found
- Only connect equipment with compatible MEC equipment
- Only operate the equipment for its intended purpose
- Never operate with guards missing or damaged
- PPE Equipment as a minimum should be worn at all times according to this manual and as per site specifications
- Ensure Isolation Procedures are followed prior to carrying out any maintenance
- If any faults or damage to this machine are found during pre-operation checks or operation, tag the machine "Out-of-Service" and follow site procedures

Following the above mentioned and the information contained within this manual will ensure safe, efficient operation of the equipment.

3. Safety Symbols

The safety symbols and signal words, as shown below, are used to emphasise all operator, maintenance and repair actions which, if not strictly followed, could result in a life-threatening situation, bodily injury or damage to the equipment.

3.1. Safety Symbols & Signal Words



This safety alert and signal word indicates a hazardous situation which, if not avoided, <u>will</u> result in death or serious injury.



This safety alert and signal word indicates a potentially hazardous situation which, if not avoided, <u>could</u> result in <u>death or serious injury</u>.



This safety alert and signal word indicates a potentially hazardous situation which, if not avoided, <u>may</u> result in <u>minor or moderate</u> injury.



This signal word indicates a potentially hazardous situation which, if not avoided, <u>may</u> result in <u>property damage</u>.



This signal word indicates a situation which, if not avoided, <u>will</u> result in <u>damage to the</u> <u>equipment</u>.



This signal word indicates a situation which, if not avoided, <u>may</u> result in <u>damage to the equipment</u>.

3.2. Hazard Warning Signs



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all instructions to avoid possible injury or death.



This is the fire risk symbol. It is used to alert you to the potential of a fire starting if ignition sources are present.



This is the explosive risk symbols. It is used to alert you to the potential of an explosion /explosive substances present.



This is the toxic hazard symbol. It is used to alert you to the presence of toxic substances.



This is the corrosive risk symbol. It is used to alert you to the presence of corrosive substances.



This is the electric shock risk symbols. It is used to alert you to the presence of an electrical supply.



This is the battery symbol. It is used to alert you to the potential hazard of electrical supply, battery acid and leaking batteries.



This is the hot surface symbol. It is used to alert you that the surfaces may be hot.



This is the dangerous gases symbol. It is used to alert you to the presence of dangerous gases.



This is the fluid under pressure symbol. It is used to alert you that there are fluids under pressure in this machinery.



This is the sharp edges symbol. It is used to alert you to the presence of sharp edges or cutting hazard.



This is the keep hands clear symbol. It is used to warn you to keep hands clear as there are pinch points present.



This is the rotating parts symbols. It is used to warn you of rotating parts on the machinery. Keep clear of rotating parts.

3.3. Personal Protection Symbols



This is the eye protection symbol. It is used when eye protection must be worn.



This is the hearing protection symbol. It is used when hearing protection must be worn.



This is the head protection symbol. It is used when head protection must be worn.



This is the hand protection symbol. It is used when hand protection must be worn.



This is the foot protection symbol. It is used when feet protection must be worn.



This is the protective body clothing symbol. It is used when protective clothing must be worn.



This is the face protection symbol. It is used when face protection must be worn.



This is the long hair protection symbol. It is used when long hair is required to be contained or restrained.

3.4. Prohibition Symbols



This is the naked flame symbol. It is used when there is not to be a fire, naked flame, ignition sources and smoking nearby.

4. Safety Precautions

To ensure safe operation, please read and understand the following statements and their meanings. Also refer to supporting manuals from the engine manufacturer on specific operation and maintenance of the engine. This manual contains safety precautions which are outlined below.



Ensure all personnel operating this equipment are properly trained to ensure safe operation









Wear personal protective equipment around this machinery.

For example: safety glasses, hearing protection, head protection, protective clothing and safety shoes at all times.

Accidental starts can cause severe injury or death.

Disable engine by disconnecting negative

(-) battery cable. Ensure machinery is started in the neutral position.









Rotating parts can cause severe injury

Stay away whilst machine is in operation. Ensure ALL guarding is in place and secured before operation.

Hot parts can cause severe burns.

Beware of hot parts on the machinery – i.e. exhaust, engine, hoses, radiator, solenoids, exposed metal components, etc.









Carbon monoxide can cause severe nausea, fainting or death.

Avoid inhaling exhaust fumes and never operate the engine in a closed or refined area.



Fuel can cause fires and severe burns.

Do not fill the fuel tank while the engine is hot or running.









Explosive gas can cause fires and severe acid burns.

Charge battery only in a well-ventilated area. Keep sources of ignition away.

High Pressure fluids can puncture skin and cause severe injury or death.

Do not work on fuel or hydraulic system without proper training and safety equipment. Ensure all hose connections are tight.





Clamping parts can cause severe injury.

Stay away whilst machine is in operation.

before operation.

Ensure ALL guarding is in place and secured





Loose hair, clothing and jewellery can cause severe injury.

Ensure hair is restrained; loose clothing not to be worn and jewellery must be removed before operating the machinery.









Electrical shock can cause injury.

Do not touch wires whilst engine is running. Disconnect negative (-) battery cable before any work on wires. Attachment hoses must have a minimum working pressure rating of 2500psi.Do not use hoses and fittings that are not pressure rated.

WARNING







Ignition sources can cause fires and severe burns.

There is <u>not</u> to be a fire, naked flame, ignition sources or smoking around any MEC machinery.



Toxic and/or Hazardous substances utilised in this machinery.

Beware of toxic and/or hazardous substances used within this machinery. Do not inhale, swallow or touch toxic/hazardous substances.







Injury can occur due to terrain and operating speeds.

To ensure safe work is achieved, do not exceed walking pace whilst operating this equipment. Also note the terrain conditions (underfoot and rail conditions). Do not walk on sleepers or the rail head.



Electrification can occur if used on live third rail and/or fourth rail.

Do not use equipment on live third rail and/or fourth rail electrification.





Injury can occur through incorrect operation of the equipment.



Only operate the equipment for its intended use. Failure to do so may result in injury. Do not ride on or tow the equipment. **DO NOT** disassemble hammers without consultation with MEC.





Vibration Hazard

Normal and proper use of this equipment will expose the operator to vibration. Vibration exposure may cause and/or contribute to injury throughout the body. Ensure proper procedures are followed for vibration exposure levels to reduce the risk of injury.

Refer to Specifications for vibration level data.



Refer to Specifications for noise level data.

5. Equipment Stickers & Tags

Below are the stickers and tags utilised on this equipment.



IDTAG02 – Model & Serial No. Tag



IF THE EMERGENCY STOP IS NOT ELECTRICALLY CONNECTED TO THE TRACKPACK, THE EMERGENCY STOP BUTTON WILL NOT STOP THE MACHINE. CONTACT MELVELLE EQUIPMENT FOR MORE INFORMATION

IDTAG12 – Emergency Stop Warning Label



LAB0003 – Melvelle Newcastle Sticker



LAB0004 – Melvelle Achieving Excellence Sticker



LAB0006 – Danger – Keep Hands and Feet Clear Sticker



LAB0007 – Danger – Moving Parts Sticker



LAB0008 – Safety Label



LAB0022 - NO LASHING POINT



LAB0023 - LASHING POINT



LAB0024 - LASHING POINT ONLY, NO LIFTING

5.1. Stickers & Tags Locations





6. Emergency Stop

This machine has been fitted with an Emergency Stop to increase the operational safety of MEC machinery.



Important information about the Emergency Stop:

- The Emergency Stop is designed to stop the engine and hence the work head in Emergency situations
- Dedicated machines have a dedicated Emergency Stop to the power pack they are wired into the machine
- Trackpacks fitted with a wiring harness will not operate unless a work head with an Emergency Stop is connected and the wiring harness connectors are joined
- The Emergency Stop <u>WILL NOT OPERATE</u> unless it is electrically connected to the power pack. For Trackpack heads, if the Trackpack is not fitted with a wiring harness and plug, the Emergency Stop <u>will not work</u>
- The Emergency Stop is not intended to be used for normal stopping of the machinery

7. Introduction

Melvelle Equipment Corp Pty Ltd (MEC) supply E (& PR)-Clip Inserter/Removers to the rail industry. The 190 work head is designed to remove and install E and PR Clips (elastic fasteners) that are used to fasten the rail to sleepers. The 190 has the ability to be used on rail sizes from 41kg/m to 68kg/m rail with steel, timber or concrete sleepers.

The 190 work head removes and installs E and PR clips using hydraulic force rather than operator exertion. This significantly improves efficiency and eliminates manual handling hazards associated with installing and removing E and PR clips.

With the floating jaws producing 4 tonne of force even galvanised clips are easily inserted. Working on both sides of the rail simultaneously, the 190 clips/unclips a sleeper in 10-15 second. The 190's unique positioning method allows sleepers to drop up to 20mm without missing or incorrectly engaging the clip, making it very well suited to real track conditions.

The 190 work head is packed with features making it a valuable tool for track maintenance and construction. They include:

- Tool-free jaw change in 3 minutes
- Simple Tool-free set up on track¹
- Convenient stowage of spare jaws, including spare pins
- Unique jaw design prevents clips rotating forward ensuring they are driven in correctly.
- Clip drive adjustment, preventing over/under drive
- Maintenance free no greasing
- Single sided operation if required
- Work light
- Ergonomic, height adjustable handles
- Precisely balanced only 3-5 kg on operator
- Stowage/transport frame and lifting bar
- Designated lift point for mechanical lifting

With safety being Melvelle's 1st priority the 190 workhead has been design with the following safety features:

- Fully guarded there is no access to pinch or crush points.
- "dead man" switch requiring two handed operation.
- e-stop
- Clip retaining jaws clips cannot fly off when unclipped due to the shape of the jaws.
- All hydraulic hoses are fitted with hose protection

¹ When shoulder-shoulder centres change (i.e. sleepers differ between states) a spanner is required to adjust width.



8. Specifications

8.1. FP-190-TP- Trackpack Workhead

Engine	MEC Trackpack
Dimensions	1100mm long x 740mm wide x 1000mm high
Weight (wet)	106kg
Pressure (max)	185bar / 2700psi
Battery	12V
Hydraulic Oil ¹	ISO68
Hydraulic Hose Connection Size	1/2"
Pressure Settings:	
Cylinder retract kick-down pressure	50 bar / 720psi
Cylinder extend Pressure	185 bar / 2700psi

8.2. FP-190-TP-02A - Trackpack Workhead

Engine	MEC Trackpack
Dimensions	1100mm long x 740mm wide x 1000mm high
Weight (wet)	234lb (106kg)
Pressure (max)	185bar / 2700psi
Battery	12V
Hydraulic Oil ¹	ISO68
Hydraulic Hose Connection Size	1/2"
Pressure Settings:	
Cylinder retract kick-down pressure	50 bar / 720psi
Cylinder extend Pressure	185 bar / 2700psi

9. Operation

A WARNING

Before use of the equipment, be aware of the operating environment and conditions for which the equipment is to be used. Ensure all users are trained to operate the machinery before operation.

9.1. Operating Conditions

The following outlines the duties and conditions for which the equipment is intended to be operated:

- Used on the intended rail line (gauge)
- Used within a possession
- Not to be used on third and/or fourth rail electrification
- Has the ability to be used in all environmental conditions providing the rail is clean and accessible (i.e. snow, extreme heat, etc may be considered hazardous to operation of the equipment)
- Equipment is designed to install & remove Pandrol 'E' Clip and 'PR' Clips (elastic fasteners) only
- Ensure operators are using hearing protection when using this machinery that is applicable to industry standards to reduce noise to acceptable levels
- Ensure operators adhere to industry accepted operating times for vibration exposure levels

9.2. Pre-Operation Checks

9.2.1.1. Overall Inspection

- 1. Check that the equipment is free from damage or defects
- 2. If damaged, DO NOT USE. Contact MEC for repairs

9.2.1.2. Engine Oil

- 1. Check the level and quality of the engine oil and add if required
- 2. If contaminated or old, engine oil will be dark (nearly black)
- 3. If contaminated with water, engine oil will be a milky colour
- 4. Refer to manufacturer's instructions for specific data
- 5. If engine oil contaminated, replace before use

9.2.1.3. Hydraulic Oil

- 1. Check the level and quality of the hydraulic oil and add if required
- 2. Oil level to be just above the centre cone, under the filter breather cover, by 2-20mm
- 3. If contaminated, hydraulic oil will be discoloured
- 4. If contaminated with water, hydraulic oil will be a milky colour
- 5. If hydraulic oil contaminated, replace before use

9.2.1.4. Fuel

1. Check the level of fuel and add if required

9.2.1.5. Battery (if applicable)1. Visually inspect the condition of the battery

- 2. Ensure there is no damage, acid levels are OK and the battery leads are free from defects
- 3. If damaged, replace before use

9.2.1.6. Light1. Visually inspect condition and leads of light

- 2. Ensure there is no damage and leads are free from defects
- 3. Before starting, ensure the light is off
- 4. If damaged, replace before use

9.2.1.7. Hydraulic Hoses & Filter

- 1. Visually inspect the hoses and filter
- 2. Ensure there is no damage
- 3. If damaged, replace before use

9.2.1.8. Guards & Stickers/Tags

- 1. Inspect all guards and stickers/tags are in place and secure refer to further document drawings for locations
- 2. Ensure there is no damage
- 3. If damaged, DO NOT use machinery. Replace before use

9.2.1.9. Emergency Stop

- 1. Ensure Emergency Stop plug is electrically connected
- 2. Ensure the wires are free from damage and connections are clean and dry

9.2.1.10. Jaws

- 1. Inspect jaws for damage and wear before use
- 2. If damaged or excessive wear seen, replace jaw

9.3. Assembly Procedures

ARNING WARNING

Before any assembly and/or maintenance are performed, ensure the work head and engine are off and in a neutral position

9.3.1. Braked Machine Trolley

 Inspect the trolley and ensure it is not damaged and free from defects, and all pre operation checks are done as per section 9.2.



2. Assemble the trolley to the rail lines.

Refer to Braked Machine Trolley Operation Manual for more information



9.3.2. Machine Assembly – Trackpack

 Observe all safety precautions. Ensure the operation is being performed on safe and steady ground (no excessive slopes or dangerous terrain).

- Inspect the 190 work head and Trackpack and ensure they are not damaged and are free from defects.
- A 190 work head weighs approximately 106 kg and a Trackpack weighs approximately 120kg.
- Lift work head from vehicle, keeping stowage frame attached. Place work head onto ground
- Adjust the pivot position (cross trolley rollers) to the correct position for the machine. For the 190 this is the furthest hole from the engine (refer further document drawing for pin locations). Attach slings to the lifting lugs on the Trackpack.
- By following safe lifting procedures, lift the Trackpack using slings ensuring it is kept level and easy to move (For more information refer to the Trackpack Manual).
- 7. Guide the Trackpack towards the work head and align the square attachment (hayman-reese style) and slide the items together. Insert the locking pin between the items and lock in position with the R -Clip. Lower the Trackpack to the ground and remove the slings.
- Connect the hydraulic quick snaps together. Connect the electrical deutsch plugs together to ensure the Emergency stop and brake is connected to the trackpack.
- Un-pin the stowage frame and the trackpack / work head are now ready be lifted onto the machine trolley.









10. By following safe lifting procedures, lift the machine onto the trolley. The cross trolley rollers will sit onto the cross bar (tube).

When placing the machine onto the trolley, ensure hands are clear of the cross trolley rollers and cross bar (tube) as personal injury may occur.

- 11. Remove the slings and/or hooks. The machine can now be moved to either rail for use. This is achieved by raising the head off the ground and sliding across the trolley. A second person may be required to assist and push the engine across the trolley.
- 12. Attach the chain to the trolley to ensure the machine will not roll during operation.





- 13. Connect the Brake hose to the Cylinder on the trolley.
- 14. The equipment is now ready for use.



9.3.3. Handle Adjustment

The adjustment of the handles is done to achieve a comfortable height for the operator whilst using the machine.

To adjust the handles:

- 1. Loosen the T-Bolt and locking nut.
- 2. Remove the R-Clip and adjustment bolt from the handles.
- 3. Stand in the operating position and lift/lower the handles to the required height.
- 4. Replace the adjustment bolt and R-clip.
- 5. Tighten the T-Bolt and locking nut.



9.3.4. Machine Adjustment – Workhead Angle

The head angle adjustment is required to ensure the 190 work head is level with the rail and ensures correct engagement with the clips. This is required as the rail height changes between rail sizes and hence, the angle of the work head. Incorrect work head angle hinders the operation of the machine and operators will find it difficult to use the machinery.

To adjust the Workhand angle:



 Ensure the Workhead is on the rail and connected to a Trackpack. Turn knob to align edge to correct rail size. Tighten locking nut firmly by hand.

 Following the above steps will align the work head parallel to the rail.
Significantly worn rail may require a minor readjustment to ensure the work head is set parallel to the rail


9.3.5. Machine Adjustment - Shoulder to Shoulder spacing

In Australia there is a variety of sleepers in use with a range of shoulder to shoulder spacing. To accommodate this variation the 190 work head has some simple slide in – slide out spacers as shown below.





BOTH SPACERS ON OUTSIDE OF HEAD MODULE





*The rail guides are set 85mm apart; this is to allow for use on all rail sizes 68KG and under



9.4. Jaw Assembly

9.4.1. Concrete Sleeper, E-clip – Clipping Up



9.4.2. Concrete Sleeper, E-clip – Unclipping



9.4.3. One sided Operation

Some rail systems, such as check rail arrangements on tight bends, require single sided clipping. To achieve this, the 190 work head comes fitted with a "LOCKOUT" jaw which prevents one side of the unit from operating. It is safe to operate the machine with the "LOCKOUT" installed (as shown below) and the guard removed from the locked out side only. In some cases the inner rail guides may need to be removed as well. This will depend on the check rail used/positioned.





42



9.4.4. Timber/Composite Sleeper Terminology

The following jaw assembly guidelines for timber/composite sleepers refer to the "FIELD SIDE" and "GAUGE SIDE" of the rail. They are defined in the image below.



9.4.5. Clip Style Terminology – E-Clip/ PR-Clip

The following shows the difference between an E-clip and a PR-Clip which require different jaws. See section 15, **Error! Reference source not found.** for details on PR clips on both concrete and timber s leepers.



E-Clip

PR-Clip

9.4.6. Timber/Composite Sleeper Plate Variations

There a variety of sleeper plates currently in use. The 190 jaws accommodate the following variations:

Sleeper Plate Width



To accommodate this variation, 1 out of the 4 jaws in the set has 2 pinned positions:





Un-clipping:

Rolled or Cast Sleeper Plates



Cast Plate Backstop Orientation

A "FIELD" side backstop always stays on the "FIELD" side and a "GAUGE" side backstop always stays on the "GAUGE" side (see section 9.4.4). They are simply rotated 180 degrees for cast or rolled plates as shown below.



Rolled Plate Backstop Orientation

A "FIELD" side backstop always stays on the "FIELD" side and a "GAUGE" side backstop always stays on the "GAUGE" side (see section 9.4.4). They are simply rotated 180 degrees for cast or rolled plates as shown below.



9.4.7. Special Track Plates

For information on special track jaws and backstops go to the following appendix sections.

SPECIAL TRACK PLATE DECRIPTION	SECTION NUMBER
APPENDIX A – PR CLIP JAWS	15
APPENDIX B – 150MM (6") SLEEPER PLATE E-CLIP JAWS	16
APPENDIX C – 216MM (8.5") SLEEPER PLATE E-CLIP JAWS	17
APPENDIX D – 16" VICTOR PLATE E-CLIP JAWS	18
APPENDIX E - 18" VICTOR PLATE E-CLIP JAWS	19
APPENDIX F - PANDROL 91533 RAIL PLATE	20
APPENDIX G – DELKOR RAIL EGG RF167 & RF127 (ELASTIC RAIL FASTENER) & RF127	21

9.4.8. Timber/Composite Sleeper Cast Plate, E-clip – Clipping Up

Gauge Side (see section 9.4.4 and 9.4.6)



Field side (see section 9.4.4 and 9.4.6)



9.4.9. Timber/Composite Sleeper, Cast Plate, E-clip – Unclipping

Either Gauge or Field Side (see section 9.4.4 and 9.4.6)



Either Gauge or Field Side (see section 9.4.4 and 9.4.6)



9.4.10. Timber/Composite, Rolled Plate, E-clip – Clipping Up

Gauge Side (see section 9.4.4 and 9.4.6)



Field Side(see section 9.4.4 and 9.4.6)



9.4.11. Timber/Composite, Rolled Plate, E-clip – Unclipping

Either Gauge or Field Side (see section 9.4.4 and 9.4.6)



Either Gauge or Field Side (see section 9.4.4 and 9.4.6)



WARNING

Only authorised personnel shall start, operate or interfere with the normal working of portable machines or trolleys. The user shall be careful to use the machine in the intended way, avoiding over-loading.

9.5.1. Starting the Engine – Electric Start¹

- 1. Observe all safety precautions as per section 4.
- 2. Ensure all pre-operation checks have been conducted as per section 9.2.
- 3. Assemble the work head, track pack and trolley as per section 9.3.
- 4. Ensure Emergency Stop is electrically connected to power pack and not activated
- 5. Place the throttle at 50% power
- 6. Turn the key to its first position (on position)
- 7. Press the decompression lever and hold (if Diesel)
- 8. Turn key to second position (starting position). Hold until engine starts and the release, allowing the key to return to its first position.
 - a. If Diesel, with the decompression lever pressed, the fly wheel will quickly gain momentum (2-3 seconds) as the starter motor is activated.
 - b. With the engine spinning, release the decompression lever whilst maintaining the key in the start position.
 - c. The engine will start almost immediately. Once started return key to first position.
 - d. Note: if the track-pack has a push button start, ignore key first position steps. Pressing the push button is the same as the key second position
- 9. Place throttle in idle (min) position and allow engine to warm up refer manufacturers manual for required times

¹ Refer to engine manual for detailed engine instructions and requirements

- 10. Move throttle to required rpm position, normally full throttle¹
- 11. Power pack and hydraulic circuit are now in operation and tooling is able to be used.

9.5.2. Starting the Engine – Recoil Start²

- 1. Observe all safety precautions as per section 4.
- 2. Ensure all pre-operation checks have been conducted as per section 9.2.
- 3. Assemble the work head, track pack and trolley as per section 9.3.
- 4. Ensure Emergency Stop is electrically connected to power pack and not activated
- 5. Place the throttle at 50% power
- 6. Turn the key to its first position (on position) if applicable.
- 7. Hold the grip and pull the cord until compression is found
- 8. Completely rewind the cord (allow to retract)
- 9. Press the decompression lever (if Diesel)
- 10. Using two hands, firmly and quickly pull the cord to start
- 11. Place throttle in idle (min) position and allow engine to warm up refer manufacturers manual for required times
- 12. Place throttle at required rpm position, normally full throttle³
- 13. Power pack and hydraulic circuit are now in operation and tooling is able to be used.

¹ During first 50hrs do not exceed 70% maximum rated power

² Refer to engine manual for detailed engine instructions and requirements

³ During first 50hrs do not exceed 70% maximum rated power

9.5.3. Equipment Operation – Releasing the Brake

All new machine trolleys are fitted with fail-safe brakes. These brakes are released by hydraulic pressure, supplied by connecting the $\frac{1}{4}$ " hydraulic hose line to the trolley as stated in assembly procedures.

To release the brake on the trolley:

- Observe all safety precautions as per section 4
- Ensure all pre-operation checks have been conducted as per section 9.2
- Assemble to work head, track pack and trolley as per section 9.3
- Ensure any necessary machine adjustments have been complete as per section 9.3.4
- Ensure all hydraulic and electrical connectors are connected – these control the operation of the brakes and also the machine.
- If there is a manual pull cable for the brake manifold (small flexible cable), connect this to the trigger – as shown.
- 7. To assemble a manual pull cable to the brake trigger, slide the cable through the outer cable holder. Pull down on the cable connection at the end of the cable to open and slide over the ball located on the trigger. The outer cable should locate on the back of the outer cable holder. Adjustment of the cable may be required before and after





assembly of the cable to the trigger.

- 8. Start the engine as per Starting the Engine instructions 9.5
- 9. To release the brakes, push down the trigger on top of the handles
- 10. The brakes will release and allow movement of the machine. For further information, please see trolley manual or contact MEC.



9.5.4. Equipment Operation – Un-Clipping

- Observe all safety precautions as per section 4
- Ensure all pre-operation checks have been conducted as per section 9.2
- Assemble to work head, track pack and trolley as per section 9.3
- Ensure any necessary machine adjustments have been complete as per section 9.3.4
- Ensure the correct jaws are installed in the correct orientation as per section 9.4



- 6. Start the engine as per Starting the Engine instructions 9.5
- Squeeze and hold the left hand trigger. This will allow the cylinders to retract and the jaws to open.
- Looking through the guard at the right hand (yellow) backstop (C-E-B-U), land the work head on the clip as shown. Allow the work head to tilt with the rail cant.
- Whilst holding the left hand trigger, squeeze and hold the right hand trigger. The jaws will close and remove the clips.
- Note: Release the right hand trigger once the engine starts to lug down. The engine will stall if the right hand trigger is not released.
- 11. Releasing the right hand trigger will retract the cylinders and open the jaws.
- 12. Note: With practice, the operator will not need to look through the guard but will be able to judge the correct landing position by feel.
- 13. Note: In practice the operator's left hand generally remains fixed, activating both the left hand trigger and the brake trigger. The right hand simply controls the jaws open/close.





14. To move to the next clips, activate the brake lift switch and push the machine to the required position



9.5.5. Equipment Operation – Clipping

- Observe all safety precautions as per section 4
- Ensure all pre-operation checks have been conducted as per section 9.2
- Assemble to work head, track pack and trolley as per section 9.3
- Ensure any necessary machine adjustments have been complete as per section 9.3.4
- Ensure the correct jaws are installed in the correct orientation as per section 9.4
- 6. Start the engine as per Starting the Engine instructions 9.5
- Squeeze and hold the left hand trigger. This will allow the cylinders to retract and the jaws to open.
- Looking through the guard at the left hand (yellow) backstop (C-E,PR-B-CL), land the work head on the sleeper as shown. Allow the work head to tilt with the rail cant.





- Whilst holding the left hand trigger, squeeze and hold the right hand trigger. The jaws will close and install the clips.
- Note: Release the right hand trigger once the engine starts to lug down. The engine will stall if the right hand trigger is not released.
- Releasing the right hand trigger will retract the cylinders and open the jaws.



 To move to the next clips, activate the brake lift switch and push the machine to the required position



- Note: In practice the operator's left hand generally remains fixed, activating both the left hand trigger and the brake trigger. The right hand simply controls the jaws – open/close.
- 14. With practice, the operator will not need to look through the guard but will be able to judge the correct landing position by feel

9.5.6. Stopping the Engine¹

- 1. Place tooling and power pack to "NEUTRAL" position
- 2. Set the engine speed to idle (min) using accelerator
- 3. Turn the ignition key to OFF

¹ Refer to engine manual for detailed engine instructions and requirements

10.Disassembly Procedures

10.1. Removal of Machine from Track

- Observe all safety precautions as per section 4
- Ensure engine is off and no hydraulic flow is operating to cylinder
- 3. Disconnect the brake hose from the trolley cylinder



 Disconnect the chain from the retaining profile to release the machine from the trolley



 Lift and remove the workhead (and Trackpack) from the trolley using a certified lifting device (>250kg)

*Expected time for removal of trolley with workhead assembled is approximately five (5) minutes (using certified lifting devices). These times may increase or decrease depending on location, conditions, etc.



 Whilst still coupled together, fit work head to stowage frame as per details below. The unit can now be safely loaded onto a truck/trailer for transport.







7. If required the unit can also be further separated as shown.

10.2. Lifting the Machinery

- 1. <u>DO NOT</u> manually lift machinery
- 2. Observe all safety precautions
- 3. Ensure all pre-operation checks have been conducted
- 4. Attach slings or hooks into lifting points on the machinery see above
- 5. Using a certified lifting device to >250kg, lift the machinery to required position

11.Storage & Transport

11.1. Storage of E-Clip Machine

MEC equipment should be stored in a secure, safe, dry location to ensure the equipment is not damaged and maintained in good working order. If possible, machines may be placed onto racks or placed on the ground for storage. Storing the machines in the storage/transport frames will also help to keep the equipment free from damage and allow it to sit level.

Storage of the E-clip machine can either be done connected to a Trackpack or with the work head separate. In either case it is best to store the work head in its stowage frame. See below images for stowage frame operation.

11.2. Fitting work head to stowage frame

- Ensure all locking pins are removed from the stowage frame and position on flat ground.
- Lift work head, or assembled work head and Trackpack until the lowest point of the work head is approximately 700mm off the ground. Note the unit should lift close to horizontal to the ground for ease of assembly.
- Slowly lower the unit down and guide the rear RHS section on the unit into the rear saddle. As the saddle engages continue to lower until the front saddle engages.
- With the unit sitting in the stand insert the front and rear locking pins and retain the pins with the supplied R-clips.
- With the stowage frame attached to the work head the unit can be transported to its storage location.



11.3. Transport of E-Clip Machine – Work head only

The best and safest way to transport the work head is in the supplied stowage frame. The stowage frame has tie down points and ensures no parts of the work head such as guards are damaged from incorrect lashing or unexpected movements during transport.

- Ensure the work head is fitted and secured to the stowage frame.
- 2. There are 2 ways to hold the unit. The first and recommended way is to lash the stowage frame down. With the work head in the correct position lash the frame down using the front and rear lasing ring. This method is used when the lashing points are at ground level.
- The second method is used when the lashing points are too high to use the lashing rings such as in a box trailer. Lash around the front of the Trackpack connection point. Note observe lashing and no lashing stickers.



12.Equipment Protection & Care



- Make sure all couplers/connectors are wiped clean before connection
- The hydraulic circuit control valve in "NEUTRAL" position when coupling or uncoupling hydraulic tools. Failure to do so may result in damage to the couplers and cause overheating of the hydraulic system
- Always store hoses coupled together in a 'loop' to stop hydraulic lock due to the hoses and hydraulic oil heating
- Always store the machine in a clean dry space, safe from damage or pilferage
- Make sure the power pack hydraulic circuit PRESSURE hose (male quick disconnect) is connected the PRESSURE hose for the tool (female quick disconnect) and vice versa for the RETURN hoses. Do not reverse circuit flow. This can cause damage to the internal seals of the equipment
- Always replace hoses, couplings and other components with replacement parts recommended by MEC. Hydraulic hoses must have a minimum working pressure of 2800psi
- Always keep critical tool markings such as warning stickers and tags legible
- Power pack and tooling repairs and/or service work must only be performed by MEC or certified and authorised dealer
- Do not use the power pack and/or tooling for applications for which it is not intended
- Ensure all bolts are tight and all covers/guards are fitted

13.Maintenance

ARNING WARNING

Before any maintenance of the machine or trolley is performed, ensure the work head and engine are off and in a neutral position. Ensure all potential energy is released from the system (springs, cylinders, etc). Ensure maintenance is performed by a competent and authorised person.

13.1.1.1. Tools Required to Complete Maintenance

Below are initial tools required to complete general maintenance tasks. Additional tools may be required.

• Allen Keys (various)	
• Hammer	
• Pin Punch (1/8" or 4mm)	
Ruler and/or Vernier's	The second second
• Shifter or	
• Spanners (various)	
 Tension wrench 20-120Nm and sockets 	

13.2. Maintenance Period

REGULAR SERVICE PERIOD*			5 4	F 1 2	F 1 1 1	Everv
Deufenne et even in diested ave		Fash	Every 1	Every 3	Every 6	vear
Perform at every indicated mo	nth or operating	Each	month	months	months	,
nour interval, whichever	comes first.	use	Or 1 Ohme	Or F Ohme	Or 250hm	or
ITEM			TOULS	SUNIS	250hrs	500hrs
	T					
Fueine ell	Check level	Х				
Engine oil	Change			X (1)	Х	
Engine oil filter	Change			X (1)		x
Fuel Level	Check/Fill	Х				
Fuel Lines	Check		Х			
	Replace					Х
Fuel Filter	Check/Clean			Х		
	Change					Х
Air Filter	Check			Х		
	Replace				Х	
Engine cooling fins	Clean					Х
Rocker arms clearance	Check & set					X (2)
Injectors	Clean & set					X (2)
Spark Plug	Check				Х	
	Replace					Х
Hydraulic oil Filter	Change			X (1)	Х	
Hydraulic oil	Check	Х				
	Change				Х	
Hydraulic hoses	Check	X				
	Check/Change					X (3)
Hydraulic pump	Check			X (1) (4)		X (4)
Battery	Check	Х				
Grease Nipples	Fill			Х		

Brake Lift Switch	Check	Х		
Emergency Stop	Check	Х		
Guards	Check	Х		
Cylinders	Check			Х
Jaws	Check	Х		
Trigger cables	Check		Х	
Nuts, Bolts, Screws, Fittings	Check			Х

*If heavy machine use, the service period may be less.

- (1) First 50 hrs of use
- (2) Only to be performed by MEC or certified and authorised dealer.
- (3) A thorough inspection is required. If hoses undamaged, may leave in service. However, replace hoses every 3 years of operation.
- (4) Flow and Pressure Check

14.Troubleshooting¹

PROBLEM	POSSIBLE CAUSE	CORRECTION		
	Refer to engine manual for details			
Engine won't start	Battery charge low	Charge battery		
	Battery connections loose/not attached	Check battery connections		
	Emergency Stop not connected	Check Emergency stop connection		
	No engine oil	Check engine oil		
	No fuel	Check fuel quantity		
	Fuel filter blocked	Check fuel filter		
	Fuel solenoid is off	Check fuel solenoid position		
No hydraulic oil flow/little flow	No hydraulic oil	Check hydraulic oil level		
	Pressure and Tank (return) hoses interchanged	Check connection.		
	Operation lever in neutral	Check operation lever position		
	Couplers or hoses blocked	Remove restriction		
	Filter Blocked or Old	Replace filter		
	Hoses leaking	Check hoses		
	Contamination in relief valve	Clean relief valve		
	Pump damaged	Check pump		
Hydraulic oil overheating	Air obstruction	Remove obstruction to ensure sufficient air flow around heat exchanger		
	Incorrect oil for operating	Replace oil with correct grade		
	טוינץ/סומ סוו	керіасе он		

¹ Refer to engine manual for detailed engine instructions and requirements

	Tool valve closed	Change tool or valve to 'open centre'		
Unable to connect hoses	Oil temperature and pressure increase in hoses	Allow hoses to cool		
	Operation lever in operation position	Place lever in neutral		
Emergency Stop does not work	Emergency Stop not connected to the machine	Connect Emergency Stop to the power pack		
	Wiring and/or connections damaged	Inspect wiring and replace damaged parts		
	Switch Damaged	Check/Replace switch		
	Air in hydraulic manifold	Bleed manifold		
	No oil flow	See above		
Cylinders do not operate	Trigger cables not operating valves	Check cable adjustment, Check trigger valves are operating		
Machine does not clip up	Head spacing incorrectly adjusted	Ensure shoulder width is set. Cylinders must be directly above shoulder eye on both sides.		
	Head angle incorrectly adjusted	Ensure machine parallel with rail when sitting on sleeper		
	Incorrect jaws selected	Select correct jaws from jaw selection criteria		
	Sleeper too low	Machine can lift sleeper up to 20mm. Beyond this mechanical aids are required. Note – If the clip can sit in the shoulder eye the clipper can operate successfully.		
	Machine fowls on guide or third rail	Insert lockout jaw and use as a single sided clipper		

	Excessive ballast around backstop landing area	Clear ballast where backstop touches the sleeper and shoulder	
Machine does not unclip	Head spacing incorrectly adjusted	Ensure shoulder width is set	
	Head angle incorrectly	Ensure machine parallel with	
	adjusted	rail when sitting on sleeper	
	Incorrect jaws selected	Select correct jaws from jaw selection criteria	
	Clips rusted in beyond service	Consult MEC to use 186	
	life	dedicated E-clip remover	
	Machine fowls on guide or	Insert lockout jaw and use as a	
	third rail	single sided clipper.	
		Clear ballast where backstop	
	Excessive ballast around	touches the top of the clip and	
	backstop landing area	also where the pushing jaw	
		engages.	
Machine kicking or twisting excessively	Head spacing incorrectly adjusted	Ensure shoulder width is set	
	Head angle incorrectly	Ensure machine parallel with	
	adjusted	rail when sitting on sleeper	
	Rail guides incorrectly set	Reset position of rail guides	
15. Appendix A – PR Clip Jaws

15.1. Concrete Sleeper, PR-clip – Clipping Up



15.2. Concrete Sleeper, PR-clip - Unclipping



15.3. Timber/Composite Sleeper, Cast Plate, PR-clip – Clipping Up

Gauge side (see section 9.4.4 and 9.4.6)



Field side(see section 9.4.4 and 9.4.6)



15.4. Timber/Composite Sleeper, Cast Plate, PR-clip – Unclipping



Either Gauge or Field Side (see section 9.4.4 and 9.4.6)



15.5. Timber/Composite Sleeper, Rolled Plate, PR-clip – Clipping Up



Field side (see section 9.4.4 and 9.4.6)



15.6. Timber/Composite Sleeper, Rolled Plate, PR-clip – Unclipping



Either Gauge or Field Side (see section 9.4.4 and 9.4.6)



15.7. Steel Sleeper 80lb.C.R., **PR-clip – Unclipping and Un clipping**

Unclipping - Either Gauge or Field Side (see section 9.4.4 and 9.4.6)



Clipping Up - Either Gauge or Field Side (see section 9.4.4 and 9.4.6)



16.Appendix B – 150mm (6") Sleeper Plate E-Clip Jaws

16.1. Timber/Composite Sleeper 150mm (6") Cast Plate, E-clip – Clipping Up



Field side (see section 9.4.4 and 9.4.6)



16.2. Timber/Composite Sleeper, 150mm (6") Cast Plate, E-clip – Unclipping



16.3. Timber/Composite, 150mm (6") Rolled Plate, E-clip – Clipping Up



Field Side(see section 9.4.4 and 9.4.6)



16.4. Timber/Composite, 150mm (6") Rolled Plate, E-clip – Unclipping



17.Appendix C – 216mm (8.5") Sleeper Plate E-Clip Jaws

17.1.1. Timber/Composite Sleeper 216mm (8.5") Cast Plate, E-clip – Clipping Up

Gauge Side (see section 9.4.4 and 9.4.6)



Field side (see section 9.4.4 and 9.4.6)



17.1.2. Timber/Composite Sleeper, 216mm (8.5") Cast Plate, Eclip – Unclipping



17.1.3. Timber/Composite, 216mm (8.5") Rolled Plate, E-clip – Clipping Up



Field Side(see section 9.4.4 and 9.4.6)



17.1.4. Timber/Composite, 216mm (8.5") Rolled Plate, E-clip – Unclipping



18. Appendix D – 16" Victor Plate E-Clip Jaws

18.1. Timber/Composite Sleeper 16" Victor Plate, E-clip – Clipping Up



Field Side(see section 9.4.4 and 9.4.6)



18.2. Timber/Composite Sleeper 16" Victor Plate, E-clip – Un-Clipping



19.Appendix E - 18" Victor Plate E-Clip Jaws

19.1. Timber/Composite Sleeper 18" Victor Plate, E-clip – Clipping Up



Field Side(see section 9.4.4 and 9.4.6)



19.2. Timber/Composite Sleeper 18" Victor Plate, E-clip – Un-Clipping



20. Appendix F - Pandrol 91533 Rail Plate

20.1. Timber/Composite Sleeper, Pandrol 91533 Rail Plate, E-clip – Clipping Up



Field Side(see section 9.4.4 and 9.4.6)



20.2. Timber/Composite Sleeper, Pandrol 91533 Rail Plate, E-clip – Un Clipping

Either Gauge or Field Side (see section 9.4.4 and 9.4.6) (ALWAYS USE ON 200mm HOLES)



Either Gauge or Field Side (see section 9.4.4 and 9.4.6)



21.Appendix G – Delkor Rail Egg RF167 & RF127 (Elastic Rail Fastener)

21.1. Concrete Slab Track Sleeper, Delkor RF167, E-clip – Clipping Up



Field Side(see section 9.4.4 and 9.4.6)



21.2. Concrete Slab Track Sleeper, Delkor RF167, E-clip – Un Clipping

Either Gauge or Field Side (see section 9.4.4 and 9.4.6)



21.3. Concrete Slab Track Sleeper, Delkor RF127, E-clip – Clipping Up & Un Clipping

Jaws and Backstop assembly is identical to the RF167 plates, above. The 1900029 used as a jaw for both clipping up and un clipping on both gauge and field sides. The 1900042 used as a backstop on both sides when un clipping and the 1900085(gauge side) and 1900086(field side) as backstops when clipping up

22.Appendix H – LB-Foster Rubber Encapsulated plate. Stock 01-64-3331

***Use 6mm spacer on both heads.

22.1. Clipping Up, Standard E-clips

Gauge Side (see section 9.4.4 and 9.4.6)



Field Side (see section 9.4.4 and 9.4.6)



22.2. Unclipping, standard E-clips



23.Appendix I – RF-A Plate. Stock 01-64-3342 & 01-64-3344.

100-8lb rail - Use no spacer on both heads. (100-8LB rail, 130mm foot) 115lb rail - Use 3mm spacer on both heads (115LB rail, 139.7mm foot)

23.1. Clipping Up, standard E-clips



Gauge Side (see section 9.4.4 and 9.4.6)

Field Side (see section 9.4.4 and 9.4.6)



23.2. Unclipping, standard E-clips



Both Gauge and Field Side (see section 9.4.4 and 9.4.6)

23.3. Clipping up, Heavy duty/PR clips



Field Side (see section 9.4.4 and 9.4.6)



23.4. Unclipping, Heavy duty PR clips



24.Appendix J – RF-D plate with check rail. Stock 01-64-3347.

24.1. 100-8lb Rail set up frame as below

For the 100-8lb rail set up the angle frame (1900100) as below. Note spacer position is critical for correct alignment.



24.2. 115lb Rail set up frame as below

For the 115lb rail set up the angle frame as below. Note spacer position is critical for correct alignment.



Fit and set counterbalance spring as shown below.



Swap short hose from manifold to cylinder to longer hose supplied in kit as shown below.



24.3. Clipping Up – Heavy duty PR-Clip



Field Side (see section 9.4.4 and 9.4.6)



24.4. Clipping Up – Standard E-Clip



Field Side (see section 9.4.4 and 9.4.6)

Gauge Side (see section 9.4.4 and 9.4.6)



24.5. **Unclipping – Heavy duty PR-Clip**



Both Gauge and Field Side (see section 9.4.4 and 9.4.6)

Unclipping – Standard E-Clip 24.6.



25.Appendix K – New York concrete Sleeper.

***Use 3mm spacer on both heads.

25.1. Clipping up Standard E-clip

Both Gauge and Field Side (see section 9.4.4 and 9.4.6)



25.2. Unclipping Standard E-clip



25.3. Clipping up Heavy duty PR-clip



Both Gauge and Field Side (see section 9.4.4 and 9.4.6)

25.4. Unclipping Heavy duty PR-clip



26.Appendix L – Delkor Rail RF506-02 (Elastic Rail Fastener)

26.1. Concrete Slab Track Sleeper, Delkor RF506-02, E-clip – Clipping Up

Gauge Side (see section 9.4.4 and 9.4.6)



Field Side(see section 9.4.4 and 9.4.6)



26.2. Concrete Slab Track Sleeper, Delkor RF506-02, E-clip – Un Clipping



Field Side (see section 9.4.4 and 9.4.6)


27.Further Documents

27.1. Jaw Selection Guide

The following table summarizes where the different jaws are used. To use this table, select the sleeper/rail plate type and the type of clip. Browsing down that vertical column gives the appropriate jaws and their quantities

COMMON TRACK

						CONCRET (CAST IN S	E SLEEPER Shoulder)	TIMBER/COMP (180/2	OSITE SLEEPER 00mm)						
						E-CLIP	PR-CLIP	E-CLIP	PR-CLIP	T					
C-E-P-CL+U	JAW, E-CLIP	JP 8	<u>s</u>	UN	1900029	2]					
C-E,PR-B-CL	BACKSTOP, E & I	CLIP-UP			1900041	2	2]					
C-E-B-U	BACKSTOP, E-CL	I			1900042	2									
								2		1900050	CLIP-UP	&	UN-CLIP	JAW, E-CLIP	T-E-P-CL+U
								1	1	1900052	CLIP-UP			BACKSTOP, E & PR CLIP	T-E,PR-B-CL - GAUGE SIDE
								1	1	1900053	CLIP-UP			BACKSTOP, E & PR CLIP	T-E,PR-B-CL - FIELD SIDE
								1		1900051			UN-CLIP	BACKSTOP, E-CLIP	T-E-B-U - 2 POS
								1		1900054			UN-CLIP	BACKSTOP, E-CLIP	T-E-B-U
C-PR-P-CL+U	JAW, PR-CLIP	JP 8	<u>s</u>	UN	1900058		2								
C-PR-B-U	BACKSTOP, PR-C	1			1900059		2								
									2	1900055	CLIP-UP	&	UN-CLIP	JAW, PR-CLIP	T-PR-P-CL+U
									1	1900057			UN-CLIP	BACKSTOP, PR-CLIP	T-PR-B-U - 2 POS
									1	1900056			UN-CLIP	BACKSTOP, PR-CLIP	T-PR-B-U
]					
		LOCKOL	JT JA	W	1900048	1	1	1	1]					

QUANTITIES ARE PER WORKHEAD



SPECIAL TRACK

8.5" (216mr	n) RAIL PLATE	6" (150mm)	RAIL PLATE	PANDROL 915 (OLYMP	33 RAIL PLATE IC DAM)	DELKOR RAI (ELASTIC RAI	L EGG RF167 IL FASTENER)	DELKOR RAIL F	RF506-02 (ELASTIC ASTENER)	STEEL SLEEPI	er 801b.C.R. Rail						
E-CLIP	PR-CLIP	E-CLIP	PR-CLIP	E-CLIP	PR-CLIP	E-CLIP	PR-CLIP	E-CLIP	PR-CLIP	E-CLIP	PR-CLIP						
				2								1900050	CLIP-UP	&	UN-CLIP	JAW, E-CLIP	T-E-P-CL+U
				1								1900052-C	CLIP-UP			BACKSTOP, E & PR CLIP	T-E,PR-B-CL - GAUGE SIDE
				1								1900053-C	CLIP-UP			BACKSTOP, E & PR CLIP	T-E,PR-B-CL - FIELD SIDE
				1								1900051			UN-CLIP	BACKSTOP, E-CLIP	T-E-B-U - 2 POS
				1								1900054			UN-CLIP	BACKSTOP, E-CLIP	T-E-B-U
		2										1900061	CLIP-UP	&	UN-CLIP	JAW, E-CLIP	T-E-P-CL+U
		1										1900062	CLIP-UP			BACKSTOP, E & PR CLIP	T-E,PR-B-CL - GAUGE SIDE
		1										1900063	CLIP-UP			BACKSTOP, E & PR CLIP	T-E,PR-B-CL - FIELD SIDE
		2										1900064			UN-CLIP	BACKSTOP, E-CLIP	T-E-B-U
2												1900067	CLIP-UP	&	UN-CLIP	JAW, E-CLIP	T-E-P-CL+U
1												1900066	CLIP-UP			BACKSTOP, E & PR CLIP	T-E,PR-B-CL - GAUGE SIDE
1												1900065	CLIP-UP			BACKSTOP, E & PR CLIP	T-E,PR-B-CL - FIELD SIDE
2												1900068			UN-CLIP	BACKSTOP, E-CLIP	T-E-B-U
						2						1900029	CLIP-UP	&	UN-CLIP	JAW, E-CLIP	C-E-P-CL+U
						2						1900042			UN-CLIP	BACKSTOP, E-CLIP	C-E-B-U
						1						1900085	CLIP-UP			BACKSTOP, E-CLIP	GAUGE SIDE
						1						1900086	CLIP-UP			BACKSTOP, E-CLIP	FIELD SIDE
								1				1900180	CLIP-UP	&	UN-CLIP	JAW, E-CLIP	C-E-P-CL+U
								1				1900181			UN-CLIP	BACKSTOP, E-CLIP	C-E-B-U
								1				1900183	CLIP-UP			BACKSTOP, E-CLIP	GAUGE SIDE
								1				1900184	CLIP-UP			BACKSTOP, E-CLIP	FIELD SIDE
								1				1900054	CLIP-UP			BACKSTOP, E-CLIP	FIELD SIDE
								1				1900042	CLIP-UP			BACKSTOP, E-CLIP	FIELD SIDE
																	·
											2	1900178	CLIP-UP	&	UN-CLIP	JAW, E-CLIP	C-E-P-CL+U
											2	1900179	CLIP-UP	&	UN-CLIP	BACKSTOP, E-CLIP	C-E-B-U

QUANTITIES ARE PER WORKHEAD



VICTOR PLATES

18" VICTOR PLATE (554-4327)		16" VICTOR PL	ATE (554-4382)				
E-CLIP	PR-CLIP	E-CLIP	PR-CLIP				
		1		1900071	CLIP-UP		BACKSTOP, FIELD SIDE
		1		1900072	CLIP-UP		BACKSTOP, GAUGE SIDE
		2		1900073	CLIP-UP		JAW
		2		1900074		UN-CLIP	BACKSTOP
		2		1900075		UN-CLIP	JAW
1				1900076	CLIP-UP		BACKSTOP, FIELD SIDE
1				1900077	CLIP-UP		BACKSTOP, GAUGE SIDE
2				1900078	CLIP-UP		JAW
2				1900079		UN-CLIP	BACKSTOP
2				1900080		UN-CLIP	JAW

QUANTITIES ARE PER WORKHEAD



SPECIAL TRACK, NEW YORK

RFA #10 01-64-3342	00/#115 01-64-3344	RFD #10 01-64-3346,	00/#115 , 01-64-3347	LB F(01-64-3331	OSTER , 01-64-3340	CONCRET	E SLEEPER	ROL	LED TIE PLATE ("A") (7" or 7-3/4")			
E-CLIP/ (STD)	PR-CLIP (HEAVY)	E-CLIP (STD)	PR-CLIP (HEAVY)	E-CLIP (STD)	PR-CLIP (HEAVY)	E-CLIP (STD)	PR-CLIP (HEAVY)	E-CLIP (STD)	PR-CLIP (HEAVY)	JAW PART NO.	TASK	DESCRIPTION
1										1900094	CLIP UP	BACKSTOP GAUGE SIDE
1										1900095	CLIP UP	BACKSTOP FIELD SIDE
2										1900096	CLIP UP	PUSHING JAW
2										1900097	UNCLIP	BACKSTOP
2										1900098	UNCLIP	PUSHING JAW
									-			
	1									1900094	CLIP UP	BACKSTOP GAUGE SIDE
	1									1900095	CLIP UP	BACKSTOP FIELD SIDE
	2									1900115	CLIP UP	PUSHING JAW
	2									1900116	UNCLIP	BACKSTOP
	2									1900117	UNCLIP	PUSHING JAW
	-			-		-		-	-			
		1								1900099	CLIP UP	BACKSTOP GAUGE SIDE
		1								1900110	CLIP UP	BACKSTOP FIELD SIDE
		2								1900102	CLIP UP	PUSHING JAW
		2								1900101	UNCLIP	BACKSTOP
		2								1900103	UNCLIP	PUSHING JAW
						1		1		1	1	1
			1							1900099	CLIP UP	BACKSTOP GAUGE SIDE
			1							1900110	CLIP UP	BACKSTOP FIELD SIDE
			2							1900106	CLIP UP	PUSHING JAW
			2							1900104	UNCLIP	BACKSTOP
			2							1900105	UNCLIP	PUSHING JAW
				-					I			
				2						1900050	CLIP UP AND UNCLIP	PUSHING JAW
				1						1900111	CLIP UP	BACKSTOP GAUGE SIDE
				1						1900112	CLIP UP	BACKSTOP FIELD SIDE
				2						1900113	UNCLIP	BACKSTOP
			1							4000000		DUCTION OF LANK
						2				1900029	CLIP UP AND UNCLIP	PUSHING JAW
						2				1900114	CLIP UP	BACKSTOP
						2				1900042	UNCLIP	BACKSTOP
			1		1					1000050	CUD UD AND UNICUD	DUSHING IAW
							2			1900058	CLIP UP AND UNCLIP	POSITING JAW
							2			1900114	UNCLIP	BACKSTOP
	I			I	I	I	4			1900039	onocir	DAGASTOP
								2		1900050	CUP UP AND UNCUP	PUSHING IAW
								1		1900050	CLIP OF AND UNCLIP	BACKSTOP GALIGE SIDE
								1		1900052	CLIPUP	BACKSTOP FIELD SIDE 2 POSITION
								1		1900051	LINCLIP	BACKSTOP
								1		1900054	UNCLIP	BACKSTOP 2 POSITION
	1		1	1	1	1	1	4		1300034	on self.	Pression 2 Position
									2	1900055	CUP UP AND LINCUP	PUSHING IAW
									1	1900052	CLIP UP	BACKSTOP GAUGE SIDE
									1	1900053	CLIP UP	BACKSTOP FIELD SIDE 2 POSITION
									1	1900056	UNCLIP	BACKSTOP
									1	1900057	UNCLIP	BACKSTOP 2 POSITION
L			1	1	1	1	1	1	4	2300037	and the second s	and a second sec



27.2. Drawings, Diagrams and Risk Assessment

Please refer to the further documents within for drawing, risk assessment and other related information.

Further documents for the 190 Pandrol E-Clipper:

Document No.	Description	Туре	Pg. #
190-OPRA	Operational Risk Assessment	Document	115
108-215	Trolley to Power Pack Attachment	Drawing	118
143-48	Trackpack Boom Adjustment	Drawing	119
190-48	Trackpack head Assembly Drawing	Drawing	121
190-126	Hydraulic circuit diagram	Drawing	123
190-127	Electric circuit diagram	Drawing	125
190-250	Trackpack Head - Imperial	Drawing	126



27.2.1. Operational Risk Assessment

	Machine: FP	-190-TP - Pandrol	er/Remove	er						Form No.:		
	ABN										Issue Date	30/03/2016
	WORKPLACE	GENERIC HIRARC F	ORM								Version:	0
	1											
Company	MELVELLE E	EQUIPMENT CORP	Department / Workplace:	Melvelle Offices	Date of Assess	ment 30/03/2016	Commenced:	9an	n		Completed:	12md
Scope of Assess	ment: Identify the risks	s and hazards associated with t	he operation of a rail	maintenance mach	hine to insert and re	emove pandrol e-cl	ips from in situ track	s.				
Names of Risk A	ssessment Team: Gary	[,] Morris, Ben Derooy			Names of addition Assessment:	nal personnel consi	ulted during Risk		Identified limita of the operatior	tions of risk as n of the machine	sessment: Only a e.	pplies to risks identified as part
									Information Sou 2601-Two Hand	urces / Reference ed Control Dev	ces: AS4024.1-200 ice	6 Safety of Machinery, AS4024-
		RI	SK ASSESSMENT	MATRIX								
					Likelihood			1	MANAGEME		S	
	Potential Consec	quences	Almost Certain	Likely	Possible	Unlikely	Rare	11			Refer to Actio	n Plan
Keyword	Description Safety Health & Hygiene	Description Environmental	Expected to occur	Will occur occasionally	May Occur	Not expected to occur	Requires unusual chain of events		Com	nents		
Minor	First Aid Injury	On-site release immediately contained with business unit resources	Medium 8	Medium 7	Low 3	Low 2	Low 1				Design Team	
Significant	Medical Treated Injury or illness	On-site release or offsite release immediately contained with smelter resources	High 14	Medium 10	Medium 9	Low 5	Low 4		Risk Assessme	ent Referred to:		
Serious	Lost Time Injury or illness	Off-site release causing nuisance or community complaint. Breach of license condition	High 16	High 15	Medium 12	Medium 11	Low 6		Diek Assessm		Andrew Melve	lle
Severe	Fatality or Permanently disabling injury of illness	Off-site release with detrimental impact to environment or community. Repeated breach of license conditions	Extreme 24	Extreme 22	High 20	High 18	Medium 13		kisk Assessm bj	y:		
Disastrous	Multiple Fatalities or work-related fatal diseases	Toxic release off-site with detrimental impact to environment or community	Extreme 25	Extreme 23	Extreme 21	High 19	High 17		Risk Assessr recorded in the	nent findings Project Design	Design Team	
									Fol	der		
LEGEND	ACTION REQUIRED	·				NOTIFY	•	11				
LOW 1-6	Tolerable - Manage by F	Routine Procedures									Design Team, Corp.	Melvelle Equipment
MEDIUM Risk reduction required to "As low as Reasonably Practicable" ALARP 7-13						Design Team/Engineer			Risk Assessn	nent Findings		
Immediate action required to reduce risk. Authorisation required before proceeding on task						CEO communicated to:						
EXTREME 21- 25	ME 21. Intolerable. Cease activity until controls in place to reduce risk. Immediate & urgent Senior Management Team action CEO required											



		Ra	aw Risk Ratii (no controls)	ng		Residual Risk Rating (after controls)					
Ref no	Description / hazard / risk	Consequence (no controls)	Likelihood	Risk Level & Score	Controls	Consequence	Likelihood	Risk Level & Score	ls Risk Tolerable Y/N	Additional Controls Req	Action By / Name & date required
	Manual lifting of machine or segments of machine is dangerous to the operators back, and other areas	Serious	Likely	15	Use of lifting points for machines(crane) to lift the machine. No person to lift any machine at all . Lifting information supplied in manual	Serious	Rare	6	Y		
	Weight at handles through incorrect trackpack setup causing strain on operator (trackpack only)	Significant	Likely	10	Correctly adjust trackpack pin location. Details shown in manual	Significant	Rare	4	Y		
	Machine handles too low/high causing injury	Significant	Possible	9	Handles adjusted to the correct height. Procedure shown in manual	Significant	Rare	4	Y		
	Fluid levels too high causing overflow and low causing machine damage	Minor	Likely	7	Pre-start checklist requiring operator to check fluid levels before operating machine	Minor	Rare	1	Y		
	Exposure to hazardous materials such as fuel and oils	Minor	Likely	7	Hazardous material documentation in MSDS.	Minor	Rare	1	Y	MSDS	
	Fueling the fuel tank can lead to explosions, fires, and dangerous fumes being inhaled	Serious	Possible	12	Engine must only be re-filled when the power pack is stopped and in well ventilated area.	Serious	Rare	6	Y		
	Hand Injury can occur through connection of quick snap connections	Minor	Possible	3	Must be connected parellel to each other.	Minor	Rare	1	Y		
	Setting of height and backstops can lead to injury	Significant	Likely	10	Ensure machine is turned off and deadman employed. Use of manuals and procedures	Significant	Rare	4	Y	Procedure/manual	
	Injury through oil injection through hydraulic failure	Serious	Possible	12	Hose Protection installed. Maintenance/Inspection frequencies provided in manual	Serious	Rare	6	Y		
	Loud noise from engine and machine causing permanent hearing damage	Serious	Likely	15	Warning stickers instructing operator to wear hearing protection Operating instructions in Manual Instruct operator to wear hearing protection	Serious	Unlikely	11	Y		



		R	aw Risk Ratii (no controls)	ng)		Residual Risk Rating (after controls)		ng			
Ref no	Description / hazard / risk	Consequence (no controls)	Likelihood	Risk Level & Score	Controls	Consequence	Likelihood	Risk Level & Score	ls Risk Tolerable Y/N	Additional Controls Req	Action By / Name & date required
	Serious burns can occur through the touching of hot surfaces	Significant	Likely	10	Include warning signs. Include warnings in training and operating manuals.	Significant	Unlikely	5	Y	Warning sticker list	
	Battery contains corrosive material. Operator can be exposed to injury from battery acid spills	Serious	Possible	12	Batteries securely mounted.Wear protective clothing when handling battery.	Serious	Rare	6	Y		
	Trip hazard through ballast and loose items on rail way	Significant	Likely	10	Correct training in railway safety	Significant	rare	4	Y	Railway Safety Card (RISI or equivalent)	
	Crushing injury through falling machine if incorrectly supported	Serious	Likely	15	Manual provides safe operating and handling instructions	Serious	Rare	6	Y		
	Pinch points exist through the connection of power pack to trolley and powerpack to work head	Significant	Possible	9	Procedure provided in manual on connection of powerpack, trolley, and work head. Gloves to be worn	Significant	Unlikely	5	Y	procedure shown in connection of items	
	Injury through crushing during clip extraction	Serious	Possible	9	Guarding of moving parts and pinch points, Use of 2 handed controls meaning hands are at a safe area, Training of pinch areas in manual	Serious	Rare	6	Y		
	Injury Through clip projectile	Significant	Possible	9	Guarding of Clip extraction Area	Significant	Rare	4	Y		
	Injury through Kicking of machine under incorrect alignment	Minor	Likely	7	Correct training in machine setup through manual.	Minor	Unlikely	2	Y		
	Hitting of ballast by machine causing projectiles	Minor	Likely	7	Guarding of machine. Adequate cleaning of ballast shown in manual	Minor	Unlikely	2	Y		
	Pinch point injury to hands when changing operating sides	Minor	Possible	3	Follow procedure in operating manual, ensuring PPE instructions followed.	Minor	Rare	1	Y	Procedure/manual	









27.2.3.







120



27.2.5. Trackpack Head Assembly Drawing



Operation Manual | FP-190

121

	1	UR	YOL 3	_		IS TADL	THORNEY IN AL				t -
A I	NM12ISO10Z	(CENTRE F	RAM	E TO E	ND CAPS	100	vm)	N/	A	
											A
56			(1	1)							
		/					2				
	6	~			1						
		C	~				T				
			L	-			~				
1			X								
	Cor a		- P								В
		-									
-											
											C
											C
											C
											C
											C
											C
	F	11 1	1/09/2022	88	1938	HOSES CH BLECTIS-1	ANGED TO AND TO HE	TYLE XXEL Meets	85	88	C
		11 10	1/09/2022	86 DB	1538	HORES LE ELECTUS ALONG ANT PCLAWS	ANGED TO DARIS 15 IGD ADDED TO PIC IGD ADDED TO PIC IGD ADDED TO PIC IGD ADDED TO PIC IGD ADDED TO PICO IGD ADDED TO PICO IGD ADDED TO IGD ADDED IGD AD	TYLE XXEL NERS, IOM	85	85 88	C
		11 1 10 9 1 8 1	1/09/2022 8/10/2021 8/10/2021	88 D8 JMC D8	1938 1879	HDSES CH BLECTJIS- ALDIG WIT GUARDS CH SHM SEG SHM SEG SHM SEG	ANGED TO MENU 31 GO ADDED TO RE NOT STATUS AND AND AND AND AND AND ANGED FROM 1900 INANGED FROM 1900 INANGED TO SHAIL	171.E 3061. 00M 1045, 025 8.ATE	88 88 88	BB BB BB	C
		11 1 10 9 1 8 1 7 1 6 1	1/09/2022 1/19/2022 8/10/2021 6/27/2019	88 DB JMC DB JMC	1938 1879 - 1833 1652 -	HOSES CH ELECTD15- ALDIG WITH P-CLAVP B BMG GUARES CH CHANCED V CHANCED V	ANCED TO NEW ST GO ADDED TO NEW ST GO ADDED TO NE HSQUIRED PASTE OTS CHANCED FOR HSQCE TO MARCE FROM HSQC HSQCE TO MARCE FROM HSQC HSQCE TO MARCE TO MARCES F MARCE TO MARKES F MARCE TO MARKES F MARKET MARKES F	TYLE XXEL XXERX XXEX XXEX XXEX XXEX XXEX X	55 58	88 88	C
		11 1 10 9 6 1 7 6 5 1 4 1	1/09/2022 8/10/2021 8/10/2021 3/10/2021 3/10/2021 3/10/2021	88 D8 JMC D8 JMC B8 B8	1538 1873 1633 16520	HORES CH ELECTLIS-I ALDING WITH GUARDS CH SIMING CHANCED L CHANCED L CHANCED CH CHANCED CHANCED L CHANCED CHANCED L CHANCED CHANCED CH	ANSED TO NEW ST GO AGOED TO RE NEQUERC NEW ST NEQUERC NEW ST ST TO MINISO ANSEE FROM ST ST ST ST ST ST ST ST ST ST ST ST ST S	TYLE XDEL NORS, IOM NORS, 025 ROM HOSE ROM	85 88 3 3 3 4 6 8 9 8 9 8 9 8 9 1 9 4 1 1 9 1 1 9 1 1 9 1 1 9 1 1 9 1 1 1 1	BB BB JIMC BMD	C
		11 1 10 9 1 6 1 5 1 1 3 1 2	1/09/2022 1/19/2022 8/10/2021 8/10/2021 3/10/2001 3/10/2017 3/10/2017 3/10/2017	86 DB JMC DB JMC BB JMC GM	1938 1879 - 1833 1652 - 1620 - 1620 - 1488 1465	HOSES CH ELECT315-1 FALORG WITH PC-LANP B MM3040 C TEST POINT CHANGED MANT REMOVED P	ANCED TO NEW ST GO ADDED TO ME HEQUIRED HATE DIST OF MANDED HATE STATE OF MANDED HATE OF TO HATE HATE OF TO HATE OF TO HATE OF TO HA	TYLE DOEL NERS, DOAS, OZS RATE ROM HOSE VPS AT S INEW	BB BB - BB JMC BMD BMD BMD B3	BB BB JMC BMD BMD	
		11 1 10 3 9 1 6 1 5 1 4 1 3 2 1 2 1 2	1/09/2622 8/10/2021 8/10/2021 3/10/2021 3/10/2021 3/10/2021 3/10/2021 3/10/2021 7/10/2017 7/10/2017 3/10/2017 3/10/2017	88 D8 JMC 06 D8 B8 88 88 B6 GM 6 B8	1938 1879 1833 1652 1620 1591 1488 1465 1353 1364	HORES CH ELECTLIS-I ALONG WIT- GUARDS CH CHANGED LI CHANGED LI CHA	ANGED TO NEW ST GO AGDED TO RC NEQUERED AND ANGED FROM ISO 14NGED TO SMIT INNED TO SMI	171.E 200EL 2005 2005 2005 2005 2005 2005 2005 200	B5 B8 JMC BMD BMD BMD BMD BMD BMD BMD BMD BMD BMD	BB BB JMC BMD BMD BMD BMD	
Mehreik	e Equipment Corp.	11 1 10 9 1 9 1 5 1 3 1 2 1 1 2 0 1 1 2 0 1 1 2 0 1 1 2	1/09/2022 (/10/2022 (/10/2021 (/10/2021 (/10/2021) (/10/2021) (/10/2021) (/10/2021) (/10/2021) (/10/2021) (/10/2021) (/10/2021) (/10/2022) (/10/2021) (/10/2022) (/10/2021) (/10/2022) (/10/2021) (/10/2022) (/10/202) (/10/2022) (/10/202)	88 D8 JMC D8 JMC B8 B8 JMC GM B8 C C C C C	1938 1879 1633 1652 1659 1488 1485 1354 1489	HOSES CH ELECT315-1 FALORG WITH PC-LAXP B BMD CHANGED MANUE CHANGED MANUE CHANGED MANUE REMOVED P ADDED LIGHT REMOVED P ADDED LIGHT FTTTTTTTTTTTTTTTTTTTTTTTTTTTTTTTTTTT	ANGED TO NEW ST GO ADDED TO ME HEQUIRED ASTE OTS GIANCE TO MISSION HEQUIRED ASTE OTS GIANCE TO MISSION HOUSE AND AND AND AND HARCH TO AND AND AND HARCH TO AND AND AND HARCH TO AND AND AND HARCH TO AND AND AND AND AND AND AND AND AND HARCH TO AND AND AND AND AND AND AND AND AND HARCH TO AND AND AND AND AND AND AND AND AND AND AND AND AND AND AND AND AND AND AND	TYLE DOEL NERS, DASS, DASS, DASS, NEW HOSE F SAND P F SAND P F O D	B8 B8 JMC BMD BMD B8 GM GM	BB BB JMC BMD BMD BMD BMD BMD	
Pedvella	e Reportert Corp.	11 1 10 9 1 9 1 9 1 1 2 1 2 0 1 1 2 0 1 1 2 0 1 1 2 0 1 1 2 1 2 0 1 1 2 1 2 0 1 1 2 1 2 1 2 1 2 1 2 1 2 1 2 1	1/09/2622 8/10/2621 8/10/2621 3/10/2621 3/10/2627 3/10/2617 3/10/2	BB DB JMC DB JMC GM BB BB JMC GM C C C C C C C C C C C C C C C C C	1938 1879 1833 1652 1620 1591 1488 1465	HORES CH ELECTUS- ALONG WIT- GUARDS CH GUARDS CH SIM 3440 CHANGED L CHANGED	ANKED TO NEW ST GO ACRED TO RC NEQUERED AND NEQUERED AND ST TO BMISSO TO ST OF MARKED FROM ISO 1300H6 INACED FROM ISO STORE TO SMISSO INFORMATION NECESSION LINK NEW TO SMISSO INFORMATION NEW TO SMISSO	NOLE XOEL NOES NOM NOES, 025 ROM HOSE S S NOEX HOSE FF FP- FP- FP-	88 88 99 940 940 940 940 940 940 940 940 940	88 88 99 94 94 94 94 94 94 94 94 94 94 94 94	C





Operation Manual | FP-190





Operation Manual | FP-190

123

				_		6				
										Ą
	LOCTITE 243 INTO POSITI	FITT.	INGS						8	в
										c
Ter la constant de la	web: Equipment Corp.	11 1/0 10 1/1 9 8/1/3 8 8/2 6 17/ 5 13/ 4 10/1 3 3/0 2 7/1 1 29//0 REV [TOLERAM XX = 0.1	9/2022 9/2022 0/2021 0/2021 0/2017 10/2017 10/2017 0/2016 11/2015 MTE CES UN XXXX.	BB DB JMC DB DB JMC BB JMC GM BB BB - DPN CO:- 1 2.0 ±2.0	1938 1879	HOSES CHANGED TO NEW ST ELECTSIS-MOD ADEED TO MOI ALONG WITH REQUIRED INSEE PCLAMP BOLTS OBJECT MOI ALONG WITH REQUIRED INSEE INSEED TO INSEED THE INSEED INSEED TO INSEED THE INSEED INSEED TO INSEED THE COMMEND TO INSEED TO INSEE COMMEND TO INSEED TO INSEE INSEED LONG PETTON LINK H WAS HOUTED AND TRUCK INSEED COMMEND LINK H INSEED LONG PETTON LINK H WAS HOUTED AND TRUCK INSEED LONG PETTON LINK H INSEED LONG PETTON LINK H	YLE (I) DEL LERS, MM J MASS, J ATE J NOM B OSE B NEW I AND P Q C C	BB BB BB BB BB MC	BB BB BB JMC BMD BMD BMD GM · APP	D
Wa Ph Fox IF	10 Rogilla Ciose bisend N.S.W 2287 +61 02 4951 5244 +61 02 4951 5244 IN DOUBT, ASK!	X ±0.2 X. ±0.5 XX. ±1.0 DRAWN garym OHECKED	X ⁰ ±(X. ⁰ ±(DAT 17/02/3 APPRO 0 and the It is n	0.1° 0.5° E 2015 VED	SCALE 1:2.5 mts with e copied	RACKPACK HEAD	FP-1 MODEL 9a 0-48 pment Cor	90-T	Р ВУ 11	





124

nm UNO	0	15/10/12	GM	ORIGINAL ISSUE	
UNO:-	REV	DATE	DRN	DESCRI	IPTION
X. ±2.0		DES	CRI	PTION	PART#
K. ±3.0 ±0.1° ±0.5°	F	190 1708 AI			FP-190-TP
DATE	•	וח			AUTOCAD
1/2015		נס	IAG	KAM	DRAWING
ROVED	SC	ALE			
GMM	N	ts 🤍		182-190	-170 🛱 🐧
the con be copi	tents v ed, dis	within are the stributed or u	e prope sed in	erty of Melvelle Equipm any other manner that	nent Corp. Pty. Ltd. n that intended.





, <u> </u>		2	ELECTRIC SOLEROID CARTRIDGE 5 WAT STOOL	1 1,7	1430124-02		Melvelle Equipment Corp.	TOLEREN	ICES UNO:-	
6	5	2	LIMIT SWITCH FOR SOLENOID OPERATION	N/A	TBA		Pty. Ltd.	.XX ±0.1	XXX. ±2.0	
5	;	1	TOGGLE SWITCH ON/OFF WITH ON/OFF TAB	N/A	ELECT123		ma .	.X ±0.2	XXXX. ±3.0	_
4	ł	1	LS3 LIMIT SWITCH	N/A	ELECT100			X. ±0.5	.X° ±0.1°	
3	;	1	DT2 FEMALE HOUSING 2 WAY	N/A	ELECT96		E	XX. ±1.0	X.° ±0.5°	
2	2	1	DT8 MALE HOUSING 8 WAY	N/A	ELECT92			DRAWN	13/11/2015	
1		1	EMERGENCY STOP ENCLOSURE	N/A	ELECT69		Wallsend N.S.W. 2287			-
ITE	EM	QTY	DESCRIPTION	LENGTH	PART No.		Ph: +61 02 4951 5244 Fax: +61 02 4950 1291	GarvM	AdrianG	_
		-	MATERIAL/CUT LIST			1	IF IN DOUBT, ASK!	This drawin It is	g and the conte not to be copier	en d,



	SV08- LOCAT	-01 SE ED IN	ILEND I WDF	ID CAR RKHEAD	TRIDGE MANIFOL	D
Br	~					
\setminus	SV08 LOCA	-02 S FED IM	DLENI N WDF	JID CAF RKHEAD	RTRIDGE MANIFOL	D
		DIM	INSIONS	IN mm UNC)	
)	DE	SCRIF	PTION	1	PAR	T#
EL	TRAC ECTF	CKPAC RIC S	ck hi Chei	EAD MATIC	TP HE	
5		* -	নতা	0.40	DRAWI	NG
NT	s (\mathbb{P}	1 <u>8</u>	3-19	J-127	<u> </u>
ntents w pied, dist	ributed o	r used in	any of Me	r manner th	an that intend	ed.



27.2.8. Trackpack Head Assembly Drawing - Imperial Version (USA)

Operation Manual | FP-190











TOROUE SETTINGS TABLE								
	DESCRIPTION	- TORQUE (N	m) LOCTITE					
	PISTON ROD TO END CAP	120	N/A					
	CARRIAGE INSERTS AND LANYARDS	10	N/A N/A					
_	TOP GUIDE ROD TO END CAPS	22	N/A					
L	END CAPS TO CENTRE TUBE	80	243					
	^	1						
				А				
	<u> </u>			-				
	_			_				
				В				
1								
1								
l								
	A A A							
_								
				С				
				-				
	1 20/09/2016 BMD -	WAS 40 Nm	BMD BMD					
	0 30/11/2015 OF	IGINAL ISSUE	Unio Drib					
	REV DATE DRN CRF D	ESCRIPTION	CHK APP	D				
p.	TOLERANCES UNO:- DIM	INSIONS IN mm UNO						
	.XX ±0.1 XXX ±2.0 DESCRIP	TION	PART #					
	X. ±0.5 ,X° ±0.1°		1900015					
	XX. ±1.0 X.º ±0.5° HEAD ASS	EMBLY	1500015					
	DKAWN DATE		MODELLED BY					
7	CHECKED APPROVED SCALE							
4	GM GM 1:2	<u>18 2-19</u>	ノーンコ 🔛 1					
I	This drawing and the contents within are the prope It is not to be copied, distributed or	rty of Melvelle Equip used in any other ma	ment Corp. Pty. Ltd. Inner.					
		6						
	1							



			1	2	3		4	í	5
А									
В								3	2
C					5				
	18 17	4	LANYARD 1.5mm 7X7 SOFT LOOP TO STEEL EYE 250mm OAL SOCKET HEAD CAP SCREW M12 X 35	LANYARD0150250-SLSE7 SHM1235	(18 12		R	
64	16 15 14 13 12 11	2 2 10 4 4 2 16	SOCKET HEAD CAP SCREW M12 X 130 GR12.9 BLACK NUT M20 NYLOC NUT M12 NYLOC NUT M8 NYLOC KEY RING 19mm OD x 1.25mm CS NICKEL PLATED COPPER FLAT WASHER ENGINEERS 20mm FLAT WASHER - FNGINEERS - 1/2" X 1" ZINC	SHM12130-129BL NM20N NM12N NM08N KEYRING19125-CN FWM20 FW08		(1)			11 15
D	9 8 7 6 5 4	8 4 4 1 1 1	FLAT WASHER - ENGINEERS - 5/16" X 5/8" ZINC BOLT HT M8 X 25 ZINC QUICK RELEASE PIN, 12x40, SS - CHAMFERED/ LOCTITED MAIN TUBE 75mm CYLINDER ASSEMBLY LEFT HAND CYLINDER ASSEMBLY RIGHT HAND	FW05 BM0825 1900031 1900016 1900009 1900008					Melvelle Equipme Py, Ltd
	3 2 1 ITEM	1 2 QTY	TOP GUIDE ROD FABRICATION CARRIAGE FABRICATION END CAP MACHINED DESCRIPTION PARTS LIST 1	1900007 1900005 1900002 PART NUMBER 2	 3		4	2 OF 2 SHEET # S	ISO VIEW Fax: 161 02 495 FBI: 461 02 495 FBI:

