


# Rail Pulling Clamp

Designed for pulling rail section. T

o pull a section of rail unbolt clamp, fit anywhere along the rail and re-assemble.

The unique over centre cam locks onto rail when load is applied which prevents slippage.



| Part Number | Suits Rail Capacity | Pulling Capacity | Dimensions in mm |     |     |     |     | Weight |
|-------------|---------------------|------------------|------------------|-----|-----|-----|-----|--------|
|             | kg/m                | Tonnes           | A                | B   | C   | D   | E   | kg     |
| 1121119     | 41-60               | 20               | 220              | 170 | 195 | 105 | 255 | 32     |
| 1121119-68  | 68                  | 20               | 220              | 170 | 195 | 105 | 255 | 31.5   |

## Melville Equipment Corp Pty Ltd

ABN: 55 123 570 356  
 Address: 10 Rogilla Close  
 MARYLAND NSW 2287  
 AUSTRALIA

Phone: 61 2 49 515 244

Fax: 61 2 49 501 291

Email: [sales@melville.com.au](mailto:sales@melville.com.au)

Web: [www.melville.com.au](http://www.melville.com.au)