





NO.	Part NO.	Description	Qty
1	1E34FG.1.1	Screw	1
2	1E34FLG.1-1	Cleaner Outside Cover	1
3	1E34F.1-1	Filter Net	1
4	GB70.1+GB97.1	Screw M5x55	2
5	GB845-ST4.2x12-F-H	Screw	1
6	1E34F.1.1	Cleaner Inside Cover	1
7	1E34F.1-3	Choke	1
8	1E34F.1-2	Choke Handle	1
9	1E34F.13C	Carburetor	1
10	HP23-7	Gasket	1
11	GB70.1	Screw M5x20	2
12	GB70.1+GB93+GB97	Screw M5x30	2
13	1E34F-E.8	Admitting Pipe Ass'y	1
14	1E34F-2	Gasket	1
15	1E34FLG-3	Cylinder	1
16	HA28L-6	Gasket	1
17	1E34F.6-5	Piston Ring	1
18	1E34F-E.4-1	Piston	1
19	7DS260-28.1.3	Guide Cover	1
20	1E34F.6-3	Piston Pin	1
21	1E31F.4.1	Bearing	1
22	1E34F.6-2	Ring	2
23	7DS260-28.1.6-1	Crank Case	1
24	1E36F.2	Seal	2
25	GB/T 276	Bearing 6001/P6	2
26	7DS260-28.1.7.1	Crank Shaft	1
27	1E40FP-3Z.3-1	Key	1
28	1E34F.7-2	Gasket	1
29	GB/T119.2	Pin 4h8x10	2
30	GB70.1+GB93+GB97	Screw M5x20	5
31	1E32FL-4	Gasket	1
32	1E34FLG.3-1	Air deflector	1
33	GB845	Screw ST4.2x19	1
34	GB70.1+GB93+GB97	Screw M5x12	2
35	1E34FLG-2	Wind guide plate	1
36	L8RTC	Spark Plug	1
37	1E34FL-3E.6-1	Spring	1
38	1E34FL-3E.6.2	Cap	1
39	1E34FL-E.6-2	Crank Case	1
40	GB70.1	Screw M5x25	4
41	HA28L.4.1	Fly Wheel	1
42	1E32FL-6	Gasket	1
43	1E34FLG.5.1	Coil	1
44	1E34F.5-1	Rubber Plug	1
45	1E34FLG.5.2A	Cord Comp.	1
46	GB70.1+GB93+GB97	Screw M4x20	2
47	7DS260-28.1.8	Expander Ass'y	1
48	7DS260-28.1.8-2	Spring	2
49	7DS260-28.1.8-1	Expander Support	1
50	7DS260-28.1.8.1	Expander	2
51	7DS260-28.1.5	Clutch case	1
52	GB70.1+GB93+GB97	Screw M5x14	4

NO.	Part NO.	Description	Qty
53	1E34F-3	Gasket	1
54	7DS260-28.1.4	Muffler (without catalyst)	1
55	7DS260-28.1.4-SW	Muffler (with catalyst)	1
56	1E34FLG-1	Fuel Tank Clapboard	1
57	GB70.1+GB93+GB97	Screw M5×16	4
58	GB/T70.1+GB97	Screw M5×55-10.9	2
59	7DS260-28.1.2-1	Fuel Tank	1
60	GB70.1+GB96+GB96	Screw M5×16	2
61	GB70.1+GB96+GB96	Screw M5×20	1
62	1E36F-2C-1	Insulation pad	1
63	1E32FL.6.2-1	Fuel Tank Lid	1
64	CG420.1.3.1-2	Gasket	1
65	EB-415.4.1.1-1	Inlet	1
66	1E32FL.6.2-2	Inside Lid	1
67	1E32FL.6.2-3	Inside Lid	1
68	HB33.2.2.1	Chain	1
69	1E34FL-3E.13	Cleaner Cover	1
70	EB-415.4.2-2	Plug	1
71	EB-415.4.2-4	Fuel Pipe	85mm
72	CG420.1.3.2-2	Fuel Pipe	165mm
73	GB/T97	Chain	1
74	1E36F.1A-1	Start Handle	1
75	1E34F.11-3	Rope	1
76	1E34F.11.1-1	Pipe	1
77	7DS260-28.1.1.1	Start Cover Ass'y	1
78	1E34F.11-2	Start Rope Reel	1
79	1E34F.11-1	Recoil Spring	1
80	GB9074.6	Screw M5×10	1
81	7DS260-28.1.1	Starter	1
82	1E34FL-E.9A	Start Reel	1
83	1E34F.8-2	Start Spring	1
84	1E34F.8-1	Start Claw	1
85	HB33.2.2	Fuel Tank Lid Ass'y	1
86	7DS260-28.1.3	Cylinder cover Ass'y	1
87	7DS260-28.1.2	Fuel Tank Ass'y	1



NO.	PART NO.	PART NAME		QTY.	NO.	PART NO.	PART NAME		QTY.
1	7DS260-28A.1	Gear Case Ass'y		1	38	GB70+GB93+GB97	Screw M6×25		2
2	GB/T 893.1	Stop Ring 35		1	39	GB/T 6170	Nut		2
3	GB/T 276	Bearing 6202-2RS/P6		1	40	GB/T 93	Washer		2
4	7DS260-28.3-5	Shore Bushing		1	41	GB/T 898	Double End Studs		2
5	GB/T 276	Bearing 6202/P6		1	42	GB70+GB93+GB97	Screw M5×18		2
6	7DS260-28A.1-6	Front Case		1	43	7DS260-28A.5	Support Bracket		1
7	7DS260-28A.1-12	Output Shaft		1	44	7DS260-28A.2-1	Handle Right		1
8	7DS260-28A.1-11	Gear		1	45	7DS260-28.2-2	Bush		1
9	GB/T 894.1	Stop Ring 12		1	46	7DS260-28.2.1	Level Ass'y		1
10	7DS260-28A.1-5	Crank Case Gasket 2		1	47	CG415D.2.1-4	Button		1
11	GB/T 119	Annul 4h8×10		4	48	CG415D.2.1-3	Spring		1
12	GB/T 1152	Fuel Cup M6	7DS260-28A.2-1	1	49	CG415D.2.1-1	Clock Pin		1
13	7DS260-28A.1-4	Intermediate Case		1	50	7DS260-28.2.1-1	Control Stand		1
14	GB/T 290	Needle Bearing HK0912		5	51	GB/T 896	Stop Ring 6		1
15	GB/T 894.1	Stop Ring 20		1	52	GB/T 889.1	Nut M5		1
16	7DS260-28A.1.1-2	Shift Paddles		1	53	CG415D.2.1.2	Stop Switch		1
17	7DS260-28A.1-7	Drive Gear Shaft 1		1	54	GB/T 845	Screw ST2.9×8		2
18	GB/T 893.1	Stop Ring 24		1	55	7DS260-28.2.1.1	Stop Cord Comp.		1
19	GB/T 276	Bearing 609-2RS/P6		1	56	7DS260-28.2.1-2	Handgrip		1
20	GB/T 894.1	Stop Ring 9		1	57	7DS260-28.2.1.2	Cable Comp.		1
21	7DS260-28A.1-14	The Intermediate Reverse Gear Shaft		1	58	CG415D.2.1-2	Spring		1
22	7DS260-28A.1-8	The Intermediate Reverse Gear		1	59	GB/T 818	Screw M5×25		1
23	7DS260-28A.1-3	Crank Case Gasket 1		1	60	CG415D.2-3	Grip Right		1
24	7DS260-28A.1-1	Clutch		1	61	7DS260-28-1	Support Bracket 1		1
25	GB70+GB93+GB97	Screw M5×20		8	62	GB/T 848	Washer 14		1
26	7DS260-28A.1-2	Rear Case		1	63	GB/T 5786	Screw M14×25		2
27	7DS260-28A.1-13	Gasket		1	64	GB/T 6177	Nut M5		2
28	7DS260-28A.1-9	The Reverse Drive Gear		1	65	7DS260-28.7	Cushion Rubber Comp.		1
29	7DS260-28A.1.1-1	The Shift Gear		1	66	GB70+GB93+GB97	Screw M5×20		2
30	GB/T 119.2	Annul 6×12		3	67	7DS260-28-2	Support Bracket 2		1
31	7DS260-28A.1-10	Drive Gear Shaft 2		1	68	Tube	Tube (400mm)		1
32	GB70+GB93+GB97	Screw M4×8		1	69	7DS260-28A.3.1	Handle		1
33	7DS260-28A.1-15	Handle		1	70	CG415D.3-1	Grip Left		1
34	7DS260-28A.1-16	Spring		1	71	7DS260-28-4	Woodworker Drill Bit		1
35	GB/T 308	Steel Ball B		1	72	7DS260-28-5	Woodworker Drill Bit		1
36	7DS260-28A.1.2	Shift Claw		1	73	7DS260-28A-3	Woodworker Drill Bit		1
37	GB/T 1096	Key 4×4×10		1	74	1.5-13mm 1/2-20UNF	Drill Fixer		1